




PWRT Series

PWRF Series

User's Manual / Manual de usuario
Safety Warnings / Advertencias de seguridad



This page intentionally left blank

PROPERTY REGISTRY N° 189487
ANY REPRODUCTION IS FORBIDDEN
PROPERTY OF PROWINCH® 2019 - V1.0 ALL RIGHTS RESERVED
PROWINCH LLC COMPANY WITH QUALITY MANAGEMENT SYSTEM

PROWINCH® DISCLAIMER

Prowinch® LLC declares that it has made available to the Customer each and every one of the security warnings related to the purchased product. As a result, it does not assume any responsibility for any damages or losses that may be suffered by the client or third parties caused by a direct or indirect consequence of the breach or omission of any of the instructions or safety warnings contained in the User Manual and Security Warnings corresponding to the unit purchased.

Prowinch® LLC does not assume any responsibility or liability for accidents and / or damages to persons and / or property resulting from the negligent use of the product.

In no case does Prowinch® LLC assume any liability arising from the use of these voluntary recommendations, and does not offer any guarantee in relation to them. These recommendations do not take precedence over the current safety regulations of the plant.

For purposes of enforcing the Warranty of the product purchased, Prowinch® LLC will only be liable for any damage when it is possible to prove that the user has followed each and every one of the warnings contained in the User Manual and Safety Warnings.

1. It is the sole responsibility of the Client / User to verify that the acquired equipment, products and accessories comply with the characteristics, capacities, requirements, components, accessories and other conditions for the use that the Client / user intends to give it.
2. It is also the sole responsibility of the Client / User to ensure that the equipment and products purchased are operated and maintained with adequate safety standards and by personnel duly trained in the use thereof. The Client / User is also responsible for implementing all the security measures necessary to prevent accidents or damages to people or property and for following the indications and warnings of the corresponding manual.
3. Any assistance provided by Prowinch® LLC in the selection of the equipment, the capacities and characteristics required by the clients is delivered free of charge and based on the information about the application, use and requirements indicated by the Client itself. It does not correspond to Prowinch® LLC to verify the accuracy of the given information. It is the sole and exclusive responsibility of the Client -or who will use the equipment and products acquired- to ensure that the specifications comply with the capabilities, characteristics, up-to-date maintenance and everything necessary for a correct and safe operation in relation to the intended use.
4. Prowinch® LLC recommends the use of winches with 4 brakes for personnel lifting. The use of winches of 3 brakes or less or safety features lower than the best available for personnel lifting, is the sole responsibility of the customer.
5. In order to guarantee the safety of the personnel and users of the equipment it is necessary to carry out the inspections and maintenance of the equipment according to the recommended frequency in relation to its work cycle. It is mandatory to keep record and evidence the written and photographic reports of: Maintenance, Start-up, Load Tests, Training, Certifications, Inspections and Reports of failures and accidents.
6. The aforementioned reports must be sent by email to registros@prowinch.com within the first 7 calendar days after the occurrence of an event.
7. Compliance with the timely implementation of the mandatory activities described in points 6 and 7 in addition to all the activities mentioned in the corresponding rules applied are the sole responsibility of the user. Failure to comply with the foregoing conditions releases Prowinch® LLC from any type of Liability and Warranty to the team, customer, staff or user, or any other liability that could be attributed to Prowinch® LLC.

The information contained in this manual may contain technical errors or inaccuracies. Prowinch® LLC is not responsible for typing errors, omission or incorrect information.

This manual is subject to change without prior notice. Download the latest version available at www.prowinch.com.

Always check www.prowinch.com for the latest information regarding this product.

| | |
|--|----|
| Disclaimer | 3 |
| Safety Precautions | 6 |
| Hoist Safety Precautions | 7 |
| Before Using the equipment | 7 |
| During Operation | 8 |
| Inspection, Maintenance and repairs | 8 |
| Specifications | 11 |
| Product Code | 11 |
| Specification Chart | 11 |
| Load Level and Service Life | 12 |
| Hoist Specifications 1 Speed H3 Fixed PWRP_H3-1SW Series | 13 |
| Hoist Specifications 2 Speed H3 Fixed PWRP_H3-2SW Series | 14 |
| Hoist Specifications 1 Speed H4 Fixed PWRP_H4-1SW Series | 14 |
| Hoist Specifications 2 Speed H4 Fixed PWRP_H4-2SW Series | 15 |
| Hoist Specifications 1 Speed H3 Trolley PWRT_H3-1SW Series | 15 |
| Hoist Specifications 2 Speed H3 Trolley PWRT_H3-2SW Series | 16 |
| Hoist Specifications 1 Speed H4 Trolley PWRT_H4-1SW Series | 16 |
| Hoist Specifications 2 Speed H4 Trolley PWRT_H4-2SW Series | 17 |
| Hoist Dimensions 1 Speed H3 Fixed PWRP_H3-1SW Series | 17 |
| Hoist Dimensions 2 Speed H3 Fixed PWRP_H3-2SW Series | 18 |
| Hoist Dimensions 1 Speed H4 Fixed PWRP_H4-1SW Series | 18 |
| Hoist Dimensions 2 Speed H4 Fixed PWRP_H4-2SW Series | 18 |
| Hoist Dimensions 1 Speed H3 Trolley PWRT_H3-1SW Series | 19 |
| Hoist Dimensions 2 Speed H3 Trolley PWRT_H3-2SW Series | 19 |
| Hoist Dimensions 1 Speed H4 Trolley PWRT_H4-1SW Series | 19 |
| Hoist Dimensions 2 Speed H4 Trolley PWRT_H4-2SW Series | 20 |
| Oil & Lubricant Recommendations | 22 |
| Installation | 23 |
| Installation | 26 |
| Unpacking | 23 |
| Chain Bag Assembly | 24 |
| Electrical Connections | 25 |
| Install Trolley (models with trolley) | 26 |
| Adjust Trolley Width (models with trolley) | 26 |
| Install Trolley into Beam (models with trolley) | 27 |
| Supply Voltage | 27 |
| Operation | 28 |
| Qualified Operator | 28 |
| Handling Precautions | 28 |
| Recommended Operation | 29 |
| Parts | 35 |
| H3 Exploded view and parts list | 31 |
| Motor and body assembly drawing | 31 |
| Motor and body assembly parts list | 32 |
| Hook assembly drawing (0.5, 1, 2, 3, 5 Ton) | 33 |
| Hook assembly part list (0.5, 1, 2, 3, 5 Ton) | 34 |
| Hook assembly drawing (7.5 Ton) | 35 |
| Hook assembly part list (7.5 Ton) | 36 |
| Gear Box Assembly drawing | 37 |
| Gear Box parts list | 38 |
| Chain assembly drawing | 39 |
| Chain assembly parts list | 40 |
| Gear Box Assembly drawing | 41 |
| Gear Box parts list | 42 |
| Electric Trolley assembly drawing | 43 |

| | |
|--|----|
| Electric Trolley assembly parts list | 44 |
| Trolley assembly drawing | 45 |
| Trolley assembly parts list | 45 |
| H3 Exploded view and parts list | 46 |
| Motor and body assembly drawing | 46 |
| Motor and body assembly parts list | 47 |
| Hook assembly drawing (0.5, 1, 2, 3, 5 Ton) | 48 |
| Hook assembly part list (0.5, 1, 2, 3, 5 Ton) | 49 |
| Hook assembly drawing (7.5 Ton) | 50 |
| Hook assembly part list (7.5 Ton) | 51 |
| Gear Box Assembly drawing | 52 |
| Gear Box parts list | 53 |
| Chain assembly drawing | 54 |
| Chain assembly parts list | 55 |
| Gear Box Assembly drawing | 56 |
| Gear Box parts list | 57 |
| Electric Trolley assembly drawing | 58 |
| Electric Trolley assembly parts list | 59 |
| Trolley assembly drawing | 60 |
| Trolley assembly parts list | 60 |
| Inspection & Maintenance | 61 |
| Operation | 61 |
| Periodic Inspection | 61 |
| Troubleshooting | 65 |
| During operation | 65 |
| Power Cable | 67 |
| Motor | 67 |
| Brake | 68 |
| Inside Wiring | 68 |
| Transformer | 69 |
| Contactor & Electric Reply | 69 |
| Limit switch | 70 |
| Push Button switch | 70 |
| Electric shock | 71 |
| Hook | 72 |
| Load Chain | 72 |
| Chain Wheel | 73 |
| Load pulley and empty pulley | 73 |
| Chain guide | 73 |
| Chain wheel, junction part | 73 |
| Bearing | 73 |
| Trolley | 74 |
| Electric Trolley | 74 |
| Manual Trolley | 74 |
| Wiring Diagram | 75 |
| Conventional Hoist wiring diagram (PWRF-PWRT) | 75 |
| Hoist Wiring Diagram 1 Speed H3 Fixed PWRF_H3-1SW Series | 75 |
| Hoist Wiring Diagram 2 Speed H3 Fixed PWRF_H3-2SW Series | 75 |
| Hoist Wiring Diagram 1 Speed H4 Fixed PWRF_H4-1SW Series | 76 |
| Hoist Wiring Diagram 2 Speed H4 Fixed PWRF_H4-2SW Series | 76 |
| Hoist Wiring Diagram 1 Speed H3 Trolley PWRT_H3-1SW Series | 77 |
| Hoist Wiring Diagram 2 Speed H3 Trolley PWRT_H3-2SW Series | 77 |
| Hoist Wiring Diagram 1 Speed H4 Trolley PWRT_H4-1SW Series | 78 |
| Hoist Wiring Diagram 2 Speed H4 Trolley PWRT_H4-2SW Series | 78 |
| VFD Manual | 79 |

Thank you for purchasing our Prowinch® Electric Chain Hoist. This User Manual provides important information for personnel involved with the installation, operation, and maintenance of this product. Read this User Manual before installing, operating, or maintaining the product.

1. SAFETY PRECAUTIONS

The Prowinch® Electric Chain Hoist is designed for a safe and reliable service if operated according to the User Manual. Respect and follow all warnings for personnel and third party safety indications. Inadequate operation may cause serious risks of injuries to personnel or damage to the equipment. Read and understand this User Manual carefully before installing and commissioning the equipment. Always keep this User Manual in an accessible place for future reference. The compact and lightweight structure of the PWR and PRWC models together with their ease of use makes them a preferred hoist for daily use in factories, mines, sea ports and

warehouses. Improperly installed, maintained, or operated hoists can be the cause of serious accidents or death. This User Manual highlights symbols and notes for caution, warning and danger. Following these indications greatly improves the safety of the operator and personnel in the area.

Mandatory use of:



Hard Hat



Safety Glasses



Safety Gloves



Safety Shoes

1.1. Hoist Safety Precautions

**WARNING:**

This symbol warns for unsafe practices or situations which may cause damage to the property and even injuries to the personnel.

**DANGER:**

This symbol indicates a potentially dangerous situation which if not avoided may cause severe injuries or death

**DANGER**

All operators and other users who are near the steel chain or its load must wear required safety equipment: gloves, safety helmet / hard hat, safety shoes and eye protection.

**WARNING**

Before installing, removing, inspecting, or performing any maintenance on the hoist, the main switch must be de-energized, locked out, and tagged out. Do not use this equipment in hazardous locations.

Read and understand the contents of this User Manual thoroughly before handling the electric chain hoist. Practicing correct and safe operating procedures and carrying out the recommended preventative maintenance will ensure a long, reliable, and safe service.

After a careful study and understanding of the User Manual, store it for future reference.

1.2. Before using the Equipment:

- Read and understand the instructions in this User Manual and all the labels associated with the hoist before operating the equipment.
- Wear appropriate clothing: Do not wear jewelry or loose clothes as they can get caught by the chain or hook.
- Wear leather gloves.
- Wear non-slippery safety shoes, helmet, and eye protection.
- Perform a full check of hoist. Check for damaged parts or unusual conditions.
- Keep a safe distance: suggested distance is at least 1.5 times the length the of hoist's chain. A broken or loose chain may cause injuries or death.
- Check that the hoist and chain are properly lubricated.
- Secure the electric chain hoist to a suitable support.
- Visually inspect all electric chain hoists before each use in addition to the regular inspections and maintenance.

1.3. During Operation:


ALWAYS:

- Refer to the maximum load capacity displayed on the ID plate attached to the hoist, not the capacity of the hook.
- Stop operation immediately if unauthorized personnel enter the working area.
- Check the working condition of hoist: If the motor gets too hot stop the hoist and let it cool down for a while.
- Stop, check, and secure the load if hoist stops or loses movement during operation.
- Focus on the operation. Pay attention at all times and keep proper balance.
- Unplug the hoist after operation.



NEVER:

- **Never** exceed the maximum load capacity of the hoist.
- **Never** operate a damaged or malfunctioning hoist.
- **Never** operate the hoist if it shows an abnormal behavior.
- **Never** lift, support, or transport people or loads over people.
- **Never** Walk or step on the chain.
- **Never** operate the electric chain hoist with twisted, kinked, damaged or worn load chain.
- **Never** use the load chain as a sling around load.
- **Never** operate a hoist if the ID plate or safety labels are missing or illegible.
- **Never** operate an electric hoist if exposed to rain or water.
- **Never** use if operator is sick or not completely attentive.
- **Never** leave the hoist unattended while energized or loaded.
- **Never** operate the hoist with non-centered load.
- **Never** operate beyond the limits of the load chain or extend chain.
- **Never** use the load chain or hook as an electrical or welding ground.
- **Never** remove the labels placed on the electric chain hoist.
- **Never** use the hoist to lift load at an angle, nor pull or drag load



1.4. Inspection, Maintenance and Repairs:


- Only trained and authorized personnel may perform repairs to the equipment.
- Use only original ProWinch® parts. The use of any other part immediately voids the warranty.
- Failure to use only original ProWinch® parts may create a dangerous condition for the operator.

ALWAYS:


- Check the good condition of electrical connections.
- Check the chain and keep it lubricated.
- Prevent others from stepping under lifted load.
- Inspect and maintain the hoist regularly.
- Verify the correct installation of hoist before using.
- Avoid contact with explosive gases or materials.

NEVER:


- **Never** overload the hoist.
- **Never** transport people or animals with the hoist.
- **Never** stand under suspended load.
- **Never** use the hoist if exposed to rain, snow, or electrical storm.
- **Never** leave loads suspended for an extended period of time. This may cause component deformation and accidents.
- **Never** exceed the allowable operating temperatures stated in this User Manual (differs depending on the model).
- **Never** expose the hoist to water, sand, corrosive environment or other substances which may damage the equipment.




1. Do not overload.




2. Check the proper crimp of the electrical connections.




3. Periodically check the chain and keep it lubricated.




4. Do not transport people or animals with a hoist.




5. Do not step or walk under lifted load and prevent others from doing so.




6. Do not use the hoist if exposed to rain, snow or lightning.



7. Inspect and maintain your hoist regularly.




8. Always verify the correct hoist installation before use.




9. Do not leave the load lifted for long periods of time. It may cause deformation of the equipment and increase the risk of an accident.

Do not exceed the operating temperatures for which the hoist is designed. This range is indicated in this manual and may vary depending on the model.





Warning:



Avoid contact with gases or explosive materials.


Exposure to water, sand, a corrosive environment, or other potentially harmful elements may damage the equipment.



2. SPECIFICATIONS

2.1. Product Code.

PWR F 05 H3 - 1S W



2.2. Specification Chart (For all models of Prowinch® Electric chain hoists).

| Item | | Specs | |
|----------------------------------|-----------------------------------|---------------------------------|------------------|
| Operating temperature range (°C) | | -20° to ± 40° | |
| Operating Humidity Range (%) | | < 85% | |
| Protection Class | Hoist | IP55 | |
| | Button Switch | IP55 | |
| Power | | 3 Phases, 200V - 600 V, 50/60Hz | |
| Noise Level (db) | Single Speed Hoist | 81db | |
| | Double Speed Hoist | 81db | |
| Chain Specs | Working Load Limit | Diameter (in) | Chain Pitch (in) |
| | 0.3t - 0.5t | 0.25 | 0.4 |
| | 1t, 2t, 3t | 0.28 | 0.82 |
| | 1.5t, 2t | 0.4 | 1.2 |
| | 2.5t, 3t, 5t, 7.5t, 10t, 15t, 25t | 0.44 | 1.33 |

Observations

Do not use Prowinch® Electric Chain Hoists when the temperature or humidity exceeds the range stated in the Specification Chart.

Our hoists are designed to lift loads vertically under normal atmospheric and working conditions.

2.3. Load Level and Service Life

| Hoist Duty Class | Typical Areas of Application | Operational Time Ratings at K = 0.65 | | | |
|------------------|---|--------------------------------------|--------------------|-------------------------------|--------------------|
| | | Uniformly Distributed Work Periods | | Infrequent Work Periods | |
| | | Max. On Time, min/hr | Max. No. Starts/hs | Max. No. Time From Cold Start | Max. No. of Starts |
| H1 | Powerhouse and utilities, infrequent handling. Hoists used primarily to install and service heavy equipment, where loads frequently approach rated load, and where the hoist is idle for 1- to 6-month periods between periods of operation. | 7.5 (12.5%) | 75 | 15 | 100 |
| H2 | Light machine shop, fabricating service, and maintenance. Loads and utilization randomly distributed. Rated loads infrequently handled. Total running time not more than 12.5% of the work period. | 7.5 (12.5%) | 75 | 15 | 100 |
| H3 | General machine shop, fabricating, assembly, storage, and warehousing. Loads and utilization randomly distributed. Total running time not more than 25% of the work period. | 15 (25%) | 150 | 30 | 200 |
| H4 | High-volume handling of heavy loads, frequently near rated load in steel warehousing, machine and fabricating shops, mills, and foundries, with total running time not more than 50% of the work period. Manual or automatic cycling operations of lighter loads with rated loads infrequently handled such as in heat treating and plating operations, with total running time frequently 50% of the work period. | 30 (50%) | 300 | 30 | 300 |
| H5 | Bulk handling of material in combination with buckets, magnets, or other heavy attachments. Equipment often cab operated. Duty cycles approaching continuous operation are frequently necessary. User must specify exact details of operation, including weight of attachments. | 60 (100%) | 600 | N/A | N/A |

| Working Conditions | | Load | Time | Maintenance Interval (Months) | Expected Life [Working Hours] | | | | |
|--------------------|---|---|-------|-------------------------------|-------------------------------|------|------|------|-------|
| | | | | | 800 | 1600 | 3200 | 6300 | 12500 |
| Light | Light Mechanisms subjected normally to light loads and very rarely to the maximum load. | | | 6 - 12 | H1 | H2 | H3 | H4 | H5 |
| Normal | Mechanisms subjected normally to moderate loads and frequently to the maximum load. | < 65% | < 25% | 6 - 12 | H2 | H3 | H4 | H5 | |
| Heavy | Mechanisms subjected normally to loads of heavy magnitude and frequently to the maximum load. | > 65% | > 25% | 3 - 6 | H3 | H4 | H5 | | |
| Severe | Mechanisms subjected regularly to the maximum load | Abnormal conditions Environmental, Geographical, etc <100% < Duty Cycle Limit | | 1 - 3 | H4 | H5 | | | |

2.4. Hoist Specifications 1 Speed H3 Fixed PWRF_H3-1SW Series

| Specifications | Model | | | | | |
|------------------------|--------------|--------------|--------------|--------------|--------------|------|
| | PWRF05H3-1SW | PWRF10H3-1SW | PWRF20H3-1SW | PWRF30H3-1SW | PWRF50H3-1SW | |
| Capacity (t) | 0.5 | 1 | 2 | 3 | 5 | |
| Lifting Speed (ft/min) | 27 | 26 | 26 | 21 | 11 | |
| Motor Power (kW) | 0.75 | 1.5 | 3 | 3 | 3 | |
| Rotation Speed (r/min) | 1728 | 1728 | 1728 | 1728 | 1728 | |
| Insulation Grade | F | F | F | F | F | |
| Power Supply | 200-600V | 200-600V | 200-600V | 200-600V | 200-600V | |
| Control Voltage | 24 | 24 | 24 | 24 | 24 | |
| No. Chain falls | 1 | 1 | 1 | 1 | 2 | |
| Spec. of Load Chain | 0.25 | 0.28 | 0.4 | 0.44 | 0.44 | |
| Net Weight (lb) | | | | | | |
| Basic Dimensions (mm) | H | 540 | 650 | 800 | 845 | 1030 |
| | A | 515 | 580 | 675 | 675 | 675 |
| | B | 240 | 260 | 300 | 300 | 300 |
| | D | 285 | 300 | 430 | 430 | 430 |
| | E | 165 | 176 | 265 | 265 | 325 |

2.5. Hoist Specifications 2 Speed H3 Fixed PWRF_H3-2SW Series

| Specifications | Model | | | | | |
|------------------------|--------------|--------------|--------------|--------------|--------------|------|
| | PWRF05H3-2SW | PWRF10H3-2SW | PWRF20H3-2SW | PWRF30H3-2SW | PWRF50H3-2SW | |
| Capacity (t) | 0.5 | 1 | 2 | 3 | 5 | |
| Lifting Speed (ft/min) | 27&9 | 26&9 | 26&9 | 21&7 | 11&4 | |
| Motor Power (kW) | 0.75&0.25 | 1.5&0.5 | 3&1 | 3&1 | 3&1 | |
| Rotation Speed (r/min) | 3456&1152 | 3456&1152 | 3456&1152 | 3456&1152 | 3456&1152 | |
| Insulation Grade | F | F | F | F | F | |
| Power Supply | 200-600V | 200-600V | 200-600V | 200-600V | 200-600V | |
| Control Voltage | 24 | 24 | 24 | 24 | 24 | |
| No. Chain falls | 1 | 1 | 1 | 1 | 2 | |
| Spec. of Load Chain | 0.25 | 0.28 | 0.4 | 0.44 | 0.44 | |
| Net Weight (lb) | | | | | | |
| Basic Dimensions (mm) | H | 540 | 650 | 800 | 845 | 1030 |
| | A | 605 | 642 | 730 | 730 | 730 |
| | B | 260 | 280 | 320 | 320 | 320 |
| | D | 285 | 300 | 430 | 430 | 430 |
| | E | 165 | 176 | 265 | 265 | 325 |

2.6. Hoist Specifications 1 Speed H4 Fixed PWRF_H4-1SW Series

| Specifications | Model | | | | | |
|------------------------|--------------|--------------|--------------|--------------|--------------|-----|
| | PWRF05H4-1SW | PWRF10H4-1SW | PWRF20H4-1SW | PWRF30H4-1SW | PWRF50H4-1SW | |
| Capacity (t) | 0.5 | 1 | 2 | 3 | 5 | |
| Lifting Speed (ft/min) | 27 | 26 | 26 | 21 | 11 | |
| Motor Power (kW) | 0.75 | 1.5 | 3 | 3 | 3 | |
| Rotation Speed (r/min) | 1728 | 1728 | 1728 | 1728 | 1728 | |
| Insulation Grade | F | F | F | F | F | |
| Power Supply | 200-600V | 200-600V | 200-600V | 200-600V | 200-600V | |
| Control Voltage | 24 | 24 | 24 | 24 | 24 | |
| No. Chain falls | 1 | 1 | 1 | 1 | 2 | |
| Spec. of Load Chain | 0.25 | 0.28 | 0.4 | 0.44 | 0.44 | |
| Net Weight (lb) | | | | | | |
| Basic Dimensions (mm) | H | 455 | 520 | 640 | 685 | 870 |
| | A | 566 | 627 | 733 | 733 | 733 |
| | B | 266 | 302 | 343 | 343 | 343 |
| | D | 285 | 300 | 430 | 430 | 430 |
| | E | 165 | 176 | 265 | 265 | 325 |

2.7. Hoist Specifications 2 Speed H4 Fixed PWRF_H4-2SW Series

| Specifications | Model | | | | | |
|------------------------|--------------|--------------|--------------|--------------|--------------|-----|
| | PWRF05H4-2SW | PWRF10H4-2SW | PWRF20H4-2SW | PWRF30H4-2SW | PWRF50H4-2SW | |
| Capacity (t) | 0.5 | 1 | 2 | 3 | 5 | |
| Lifting Speed (ft/min) | 27&7 | 26&6.5 | 26&6.5 | 21&5 | 11&3 | |
| Motor Power (kW) | 0.75 | 1.5 | 3 | 3 | 3 | |
| Rotation Speed (r/min) | 1728&432 | 1728&432 | 1728&432 | 1728&432 | 1728&432 | |
| Insulation Grade | F | F | F | F | F | |
| Power Supply | 200-600V | 200-600V | 200-600V | 200-600V | 200-600V | |
| Control Voltage | 12 | 12 | 12 | 12 | 12 | |
| No. Chain falls | 1 | 1 | 1 | 1 | 2 | |
| Spec. of Load Chain | 0.25 | 0.28 | 0.4 | 0.44 | 0.44 | |
| Net Weight (lb) | | | | | | |
| Basic Dimensions (mm) | H | 455 | 520 | 640 | 685 | 870 |
| | A | 566 | 627 | 733 | 733 | 733 |
| | B | 266 | 302 | 343 | 343 | 343 |
| | D | 285 | 300 | 430 | 430 | 430 |
| | E | 165 | 176 | 265 | 265 | 325 |

2.8. Hoist Specifications 1 Speed H3 Trolley PWRT_H3-1SW Series

| Specifications | Model | | | | | |
|------------------------|--------------|--------------|--------------|--------------|--------------|------|
| | PWRT05H3-1SW | PWRT10H3-1SW | PWRT20H3-1SW | PWRT30H3-1SW | PWRT50H3-1SW | |
| Capacity (t) | 0.5 | 1 | 2 | 3 | 5 | |
| Lifting Speed (ft/min) | 27 | 26 | 26 | 21 | 11 | |
| Motor Power (kW) | 0.75 | 1.5 | 3 | 3 | 3 | |
| Rotation Speed (r/min) | 1728 | 1728 | 1728 | 1728 | 1728 | |
| Insulation Grade | F | F | F | F | F | |
| Power Supply | 200-600V | 200-600V | 200-600V | 200-600V | 200-600V | |
| Control Voltage | 24 | 24 | 24 | 24 | 24 | |
| No. Chain falls | 1 | 1 | 1 | 1 | 2 | |
| Spec. of Load Chain | 0.25 | 0.28 | 0.4 | 0.44 | 0.44 | |
| Net Weight (lb) | | | | | | |
| Basic Dimensions (mm) | H | 610 | 650 | 770 | 830 | 1015 |
| | A | 515 | 580 | 675 | 675 | 675 |
| | B | 240 | 260 | 300 | 300 | 300 |
| | D | 285 | 300 | 430 | 430 | 430 |
| | E | 165 | 176 | 265 | 265 | 325 |

2.9. Hoist Specifications 2 Speed H3 Trolley PWRT_H3-2SW Series

| Specifications | Model | | | | | |
|------------------------|--------------|--------------|--------------|--------------|--------------|------|
| | PWRT05H3-2SW | PWRT10H3-2SW | PWRT20H3-2SW | PWRT30H3-2SW | PWRT50H3-2SW | |
| Capacity (t) | 0.5 | 1 | 2 | 3 | 5 | |
| Lifting Speed (ft/min) | 27&9 | 26&9 | 26&9 | 21&7 | 11&4 | |
| Motor Power (kW) | 0.75&0.25 | 1.5&0.5 | 3&1 | 3&1 | 3&1 | |
| Rotation Speed (r/min) | 3456&1152 | 3456&1152 | 3456&1152 | 3456&1152 | 3456&1152 | |
| Insulation Grade | F | F | F | F | F | |
| Power Supply | 200-600V | 200-600V | 200-600V | 200-600V | 200-600V | |
| Control Voltage | 24 | 24 | 24 | 24 | 24 | |
| No. Chain falls | 1 | 1 | 1 | 1 | 2 | |
| Spec. of Load Chain | 0.25 | 0.28 | 0.4 | 0.44 | 0.44 | |
| Net Weight (lb) | | | | | | |
| Basic Dimensions (mm) | H | 610 | 650 | 770 | 830 | 1015 |
| | A | 605 | 642 | 730 | 730 | 730 |
| | B | 260 | 280 | 320 | 320 | 320 |
| | D | 285 | 300 | 430 | 430 | 430 |
| | E | 165 | 176 | 265 | 265 | 325 |

2.10. Hoist Specifications 1 Speed H4 Trolley PWRT_H4-1SW Series

| Specifications | Model | | | | | |
|------------------------|--------------|--------------|--------------|--------------|--------------|-----|
| | PWRT05H4-1SW | PWRT10H4-1SW | PWRT20H4-1SW | PWRT30H4-1SW | PWRT50H4-1SW | |
| Capacity (t) | 0.5 | 1 | 2 | 3 | 5 | |
| Lifting Speed (ft/min) | 27 | 26 | 26 | 21 | 11 | |
| Motor Power (kW) | 0.75 | 1.5 | 3 | 3 | 3 | |
| Rotation Speed (r/min) | 1728 | 1728 | 1728 | 1728 | 1728 | |
| Insulation Grade | F | F | F | F | F | |
| Power Supply | 200-600V | 200-600V | 200-600V | 200-600V | 200-600V | |
| Control Voltage | 24 | 24 | 24 | 24 | 24 | |
| No. Chain falls | 1 | 1 | 1 | 1 | 2 | |
| Spec. of Load Chain | 0.25 | 0.28 | 0.4 | 0.44 | 0.44 | |
| Net Weight (lb) | | | | | | |
| Basic Dimensions (mm) | H | 525 | 520 | 610 | 670 | 855 |
| | A | 566 | 627 | 733 | 733 | 733 |
| | B | 266 | 302 | 343 | 343 | 343 |
| | D | 285 | 300 | 430 | 430 | 430 |
| | E | 165 | 176 | 265 | 265 | 325 |

2.11. Hoist Specifications 2 Speed H4 Trolley PWRT_H4-2SW Series

| Specifications | Model | | | | | |
|------------------------|--------------|--------------|--------------|--------------|--------------|-----|
| | PWRT05H4-2SW | PWRT10H4-2SW | PWRT20H4-2SW | PWRT30H4-2SW | PWRT50H4-2SW | |
| Capacity (t) | 0.5 | 1 | 2 | 3 | 5 | |
| Lifting Speed (ft/min) | 27&7 | 26&6.5 | 26&6.5 | 21&5 | 11&3 | |
| Motor Power (kW) | 0.75 | 1.5 | 3 | 3 | 3 | |
| Rotation Speed (r/min) | 1728&432 | 1728&432 | 1728&432 | 1728&432 | 1728&432 | |
| Insulation Grade | F | F | F | F | F | |
| Power Supply | 200-600V | 200-600V | 200-600V | 200-600V | 200-600V | |
| Control Voltage | 12 | 12 | 12 | 12 | 12 | |
| No. Chain falls | 1 | 1 | 1 | 1 | 2 | |
| Spec. of Load Chain | 0.25 | 0.28 | 0.4 | 0.44 | 0.44 | |
| Net Weight (lb) | | | | | | |
| Basic Dimensions (mm) | H | 525 | 520 | 610 | 670 | 855 |
| | A | 566 | 627 | 733 | 733 | 733 |
| | B | 266 | 302 | 343 | 343 | 343 |
| | D | 285 | 300 | 430 | 430 | 430 |
| | E | 165 | 176 | 265 | 265 | 325 |

3. General Dimensions

3.1. Hoist Dimensions 1 Speed H3 Fixed PWRF_H3-1SW Series

| Model | Dimension (mm) | | | | | | | | | | | | | | |
|--------------|----------------|-----|-----|-----|-----|---------|---|---|---|------|----|-----|----|----|----|
| | HOIST | | | | | TROLLEY | | | | HOOK | | | | | |
| | H | A | B | D | E | R | T | W | U | I | J | K | L | M | N |
| PWRF05H3-1SW | 540 | 515 | 240 | 285 | 165 | / | / | / | / | Φ34 | 28 | Φ34 | 25 | 19 | 19 |
| PWRF10H3-1SW | 650 | 580 | 260 | 300 | 176 | / | / | / | / | Φ42 | 32 | Φ42 | 32 | 24 | 24 |
| PWRF20H3-1SW | 800 | 675 | 300 | 430 | 265 | / | / | / | / | Φ49 | 40 | Φ49 | 40 | 30 | 30 |
| PWRF30H3-1SW | 845 | 675 | 300 | 430 | 265 | / | / | / | / | Φ59 | 48 | Φ59 | 48 | 35 | 35 |
| PWRF50H3-1SW | 1030 | 675 | 300 | 430 | 325 | / | / | / | / | Φ60 | 48 | Φ60 | 48 | 43 | 43 |

3.2. Hoist Dimensions 2 Speed H3 Fixed PWRF_H3-2SW Series

| Model | Dimension (mm) | | | | | | | | | | | | | | |
|--------------|----------------|-----|-----|-----|-----|---------|---|---|---|------|----|-----|----|----|----|
| | HOIST | | | | | TROLLEY | | | | HOOK | | | | | |
| | H | A | B | D | E | R | T | W | U | I | J | K | L | M | N |
| PWRF05H3-2SW | 540 | 605 | 260 | 285 | 165 | / | / | / | / | Φ34 | 28 | Φ34 | 25 | 19 | 19 |
| PWRF10H3-2SW | 650 | 642 | 280 | 300 | 176 | / | / | / | / | Φ42 | 32 | Φ42 | 32 | 24 | 24 |
| PWRF20H3-2SW | 800 | 730 | 320 | 430 | 265 | / | / | / | / | Φ49 | 40 | Φ49 | 40 | 30 | 30 |
| PWRF30H3-2SW | 845 | 730 | 320 | 430 | 265 | / | / | / | / | Φ59 | 48 | Φ59 | 48 | 35 | 35 |
| PWRF50H3-2SW | 1030 | 730 | 320 | 430 | 325 | / | / | / | / | Φ60 | 48 | Φ60 | 48 | 43 | 43 |

3.3. Hoist Dimensions 1 Speed H4 Fixed PWRF_H4-1SW Series

| Model | Dimension (mm) | | | | | | | | | | | | | | |
|--------------|----------------|-----|-----|-----|-----|---------|---|---|---|------|----|-----|----|----|----|
| | HOIST | | | | | TROLLEY | | | | HOOK | | | | | |
| | H | A | B | D | E | R | T | W | U | I | J | K | L | M | N |
| PWRF05H4-1SW | 455 | 566 | 266 | 285 | 165 | / | / | / | / | Φ35 | 27 | Φ34 | 25 | 17 | 17 |
| PWRF10H4-1SW | 520 | 627 | 302 | 300 | 176 | / | / | / | / | Φ42 | 32 | Φ41 | 32 | 24 | 24 |
| PWRF20H4-1SW | 640 | 733 | 343 | 430 | 265 | / | / | / | / | Φ48 | 38 | Φ49 | 40 | 28 | 28 |
| PWRF30H4-1SW | 685 | 733 | 343 | 430 | 265 | / | / | / | / | Φ59 | 48 | Φ59 | 48 | 34 | 34 |
| PWRF50H4-1SW | 870 | 733 | 343 | 430 | 325 | / | / | / | / | Φ69 | 48 | Φ60 | 48 | 42 | 42 |

3.4. Hoist Dimensions 2 Speed H4 Trolley PWRF_H4-2SW Series

| Model | Dimension (mm) | | | | | | | | | | | | | | |
|--------------|----------------|-----|-----|-----|-----|---------|---|---|---|------|----|-----|----|----|----|
| | HOIST | | | | | TROLLEY | | | | HOOK | | | | | |
| | H | A | B | D | E | R | T | W | U | I | J | K | L | M | N |
| PWRF05H4-2SW | 455 | 566 | 266 | 285 | 165 | / | / | / | / | Φ35 | 27 | Φ34 | 25 | 17 | 17 |
| PWRT10H4-2SW | 520 | 627 | 302 | 300 | 176 | / | / | / | / | Φ42 | 32 | Φ41 | 32 | 24 | 24 |
| PWRT20H4-2SW | 640 | 733 | 343 | 430 | 265 | / | / | / | / | Φ48 | 38 | Φ49 | 40 | 28 | 28 |
| PWRT30H4-2SW | 685 | 733 | 343 | 430 | 265 | / | / | / | / | Φ59 | 48 | Φ59 | 48 | 34 | 34 |
| PWRT50H4-2SW | 870 | 733 | 343 | 430 | 325 | / | / | / | / | Φ69 | 48 | Φ60 | 48 | 42 | 42 |

3.5. Hoist Dimensions 1 Speed H3 Trolley PWRT_H3-1SW Series

| Model | Dimension (mm) | | | | | | | | | | | | | | |
|--------------|----------------|-----|-----|-----|-----|---------|-----|-----|-----|------|----|-----|----|----|----|
| | HOIST | | | | | TROLLEY | | | | HOOK | | | | | |
| | H | A | B | D | E | R | T | W | U | I | J | K | L | M | N |
| PWRT05H3-1SW | 610 | 515 | 240 | 285 | 165 | 355 | 231 | 206 | 111 | Φ34 | 28 | Φ34 | 25 | 19 | 19 |
| PWRT10H3-1SW | 650 | 580 | 260 | 300 | 176 | 355 | 231 | 206 | 111 | Φ42 | 32 | Φ42 | 32 | 24 | 24 |
| PWRT20H3-1SW | 770 | 675 | 300 | 430 | 265 | 355 | 231 | 237 | 127 | Φ49 | 40 | Φ49 | 40 | 30 | 30 |
| PWRT30H3-1SW | 830 | 675 | 300 | 430 | 265 | 355 | 231 | 265 | 140 | Φ59 | 48 | Φ59 | 48 | 35 | 35 |
| PWRT50H3-1SW | 1015 | 675 | 300 | 430 | 325 | 355 | 231 | 295 | 156 | Φ60 | 48 | Φ60 | 48 | 43 | 43 |

3.6. Hoist Dimensions 2 Speed H3 Trolley PWRT_H3-2SW Series


| Model | Dimension (mm) | | | | | | | | | | | | | | |
|--------------|----------------|-----|-----|-----|-----|---------|-----|-----|-----|------|----|-----|----|----|----|
| | HOIST | | | | | TROLLEY | | | | HOOK | | | | | |
| | H | A | B | D | E | R | T | W | U | I | J | K | L | M | N |
| PWRT05H3-2SW | 610 | 605 | 260 | 285 | 165 | 355 | 276 | 206 | 111 | Φ34 | 28 | Φ34 | 25 | 19 | 19 |
| PWRT10H3-2SW | 650 | 642 | 280 | 300 | 176 | 355 | 276 | 206 | 111 | Φ42 | 32 | Φ42 | 32 | 24 | 24 |
| PWRT20H3-2SW | 770 | 730 | 320 | 430 | 265 | 355 | 276 | 237 | 127 | Φ49 | 40 | Φ49 | 40 | 30 | 30 |
| PWRT30H3-2SW | 830 | 730 | 320 | 430 | 265 | 355 | 315 | 265 | 140 | Φ59 | 48 | Φ59 | 48 | 35 | 35 |
| PWRT50H3-2SW | 1015 | 730 | 320 | 430 | 325 | 355 | 315 | 295 | 156 | Φ60 | 48 | Φ60 | 48 | 43 | 43 |





3.7. Hoist Dimensions 1 Speed H4 Trolley PWRT_H4-1SW Series

| Model | Dimension (mm) | | | | | | | | | | | | | | |
|--------------|----------------|-----|-----|-----|-----|---------|-----|-----|-----|------|----|-----|----|----|----|
| | HOIST | | | | | TROLLEY | | | | HOOK | | | | | |
| | H | A | B | D | E | R | T | W | U | I | J | K | L | M | N |
| PWRT05H4-1SW | 525 | 566 | 266 | 285 | 165 | 142 | 231 | 206 | 111 | Φ35 | 27 | Φ34 | 25 | 17 | 17 |
| PWRT10H4-1SW | 520 | 627 | 302 | 300 | 176 | 142 | 231 | 206 | 111 | Φ42 | 32 | Φ41 | 32 | 24 | 24 |
| PWRT20H4-1SW | 610 | 733 | 343 | 430 | 265 | 142 | 231 | 237 | 127 | Φ48 | 38 | Φ49 | 40 | 28 | 28 |
| PWRT30H4-1SW | 670 | 733 | 343 | 430 | 265 | 142 | 231 | 265 | 140 | Φ59 | 48 | Φ59 | 48 | 34 | 34 |
| PWRT50H4-1SW | 855 | 733 | 343 | 430 | 325 | 142 | 231 | 296 | 156 | Φ69 | 48 | Φ60 | 48 | 42 | 42 |

3.8. Hoist Dimensions 2 Speed H4 Trolley PWRT_H4-2SW Series

| Model | Dimension (mm) | | | | | | | | | | | | | | |
|--------------|----------------|-----|-----|-----|-----|---------|-----|-----|-----|------|----|-----|----|----|----|
| | HOIST | | | | | TROLLEY | | | | HOOK | | | | | |
| | H | A | B | D | E | R | T | W | U | I | J | K | L | M | N |
| PWRT05H4-2SW | 525 | 566 | 266 | 285 | 165 | 142 | 276 | 206 | 111 | Φ35 | 27 | Φ34 | 25 | 17 | 17 |
| PWRT10H4-2SW | 520 | 627 | 302 | 300 | 176 | 142 | 276 | 206 | 111 | Φ42 | 32 | Φ41 | 32 | 24 | 24 |
| PWRT20H4-2SW | 610 | 733 | 343 | 430 | 265 | 142 | 276 | 237 | 127 | Φ48 | 38 | Φ49 | 40 | 28 | 28 |
| PWRT30H4-2SW | 670 | 733 | 343 | 430 | 265 | 142 | 315 | 265 | 140 | Φ59 | 48 | Φ59 | 48 | 34 | 34 |
| PWRT50H4-2SW | 855 | 733 | 343 | 430 | 325 | 142 | 315 | 296 | 156 | Φ69 | 48 | Φ60 | 48 | 42 | 42 |





4. Oil & Lubricant Recommendations



WARNING

Do not allow chain to run dry.

Lubricant greatly increases the life of load chain. Weekly lubrication and cleaning is satisfactory, but under hot, dirty, and extreme conditions it may be necessary to clean the chain at least once a day and lubricate it several times between cleaning. Apply sufficient lubricant to obtain natural runoff and full coverage, especially in interlink area.

Suspension pins should be lubricated at least twice per year for normal usage; more frequently for heavier usage or severe conditions.

| Item | Lubricant | Interval | |
|-------------------------------------|------------------------------------|---------------------------|-----------------------------------|
| | | Normal Working Conditions | Heavy / Severe Working Conditions |
| Chain | Lubriplate® Bar and Chain Oil 10-R | Weekly | Daily |
| | Gear Oil ISO46 – ISO68 | Twice Weekly | Daily |
| Gearbox | Meropa 320 (TEXACO) | Twice per year | Every other month |
| Hooks, Suspension pins & components | General lithium grease | Weekly | Daily |

WARNING

Failure to maintain clean and well lubricated load chain will void the warranty.

ALWAYS Lubricate load chain weekly, or daily, depending on service severity.

ALWAYS in a corrosive environment lubricate more frequently.

ALWAYS Use lubricant oil equivalent to ISO VG46 or VG68.

PWWA001-V1.0

1. INSTALLATION



WARNING

Before installing, removing, inspecting, or performing any maintenance on the hoist, the main switch must be de-energized, locked out, and tagged out. Do not use this equipment in hazardous locations.

Installation Process:

- Electric chain hoists must be grounded properly.
- Lock-out and tag-out the main disconnect switch in de-energized position before performing any service on hoist.
- Customer must provide power supply cable, fuses, and main disconnect switch.
- Check supply voltage is same as nameplate voltage on hoist.
- Check voltage does not vary by more than $\pm 10\%$ from nominal value.
- Do not use conductors smaller than those listed in this User Manual to supply power to hoist.
- Never bypass limit switches, remove limit switch stops, or alter limit switch devices.

1.1 Unpacking

Hoist should be carefully inspected upon delivery for any damage that may have occurred during shipment or handling. Check the hoist frame for: dents or cracks, external cords for damaged or cut insulation, control station for cut or damaged enclosure, and load chain for nicks and gouges.

| | |
|---------------------|-------|
| 1 Chain bag (box) | 1 pcs |
| 2 Control wire rope | 1 m |
| 3 Button switch | 1 pcs |

Check and document hoist characteristics:

- a. Model number
- b. Rated capacity (tonnage)
- c. Lifting length of load chain (meter)
- d. Power supply
- e. Push button pendant assembly (2 button, 4 button or 6 button)
- f. Specially ordered optional items
- g. Beam width for trolley installation



1.2 Chain Bag Assembly

4.3.1 Before installing the hoist, please confirm the whole upper hook assembly has been firmly assembled to the hoist body (ensure the chain connection pin is installed properly).

Remarks :If the hoist is equipped with electric trolley, the first step (to separate the upper hook from the hoist body) can be omitted, it is only required to install the hoist between two side plates of trolley, and lock the upper hook.

4.3.2 Assemble chain bag (Fig.4.1)

4.3.3 Link the power supply and operate the push button, the procedure should be performed by professional trained person. (Fig.4.2)



1.3. Electrical Connections

Operator and/or owner must provide main power supply hardware (cable, conductor bar, fuses, disconnect switch, etc.)



WARNING

Fuses and other current overload devices must be in place to protect power supply.


Do not use power supply cables with solid conductors.

An improper or insufficient ground connection creates an electrical shock hazard when touching any part of hoist or trolley



1.4. Install Trolley (models with trolley)


- 1.- Insert suspension pins into lateral plate G and lock it with suspension pin bolts and nuts.
- 2.- Install suspension pin with adjusting disk.
- 3.- Install suspension pin into hanger T. The nameplates of hoist and trolley should be in the same direction.
- 4.- Install additional gaskets into suspension pin before inserting it into lateral plate S.
- 5.- Install outside adjusting disk and spacer pin into suspension pin. Insert cotter pin into spacer pin.
- 6.- Cotter pin should be seen at the left side from front of trolley switch box.



(Fig.4.6)

1.5. Adjust Trolley Width (models with trolley)

- Adjust width of trolley according to drawing (below) for appropriate clearance.
 - Size A is the dimension of two side plates that stretch outside completely.
 - Size A must be approximate B (the width of rail flange) + 4mm.
 - Adjust size A by increasing or decreasing adjusting disk.
- Insert cotter pin into spacer pin and bend two branches of cotter pin until size A is correct.



Nut must be tight, insert cotter pin and bend it completely.

1.6. Install Trolley into Beam (models with trolley)

1. Install trolley at end side of beam and slip trolley which has already been connected with hoist to the appropriate place. This is the preferred method.


2. If first method is unavailable:

a) Unload brake stopper from hole A on suspension pin, and insert it into hole B. Insert cotter pin again and bend it completely.

b) Pull side plate S and G outside, then lift trolley until orbit wheel and orbit surface are in same horizontal position. Put orbit wheel of side plate G onto surface of orbit.

c) Hold side plate G and stop it from dropping from orbit. Firmly push side plate S and put its orbit wheel onto surface of beam.

d) Unload brake stopper from hole B and insert into hole A. Do not forget to bend cotter pin.



1.7. Supply Voltage



WARNING

Check supply voltage before everyday use. If voltage varies more than 10% of rated value, electrical devices may not function normally and cause damage to equipment.



WARNING

Do not connect equipment to power supply before completing the installation process.

1. OPERATION

1.1. Qualified Operator

Hoist operators are required to read and fully understand the operation section of this manual, all warnings contained in the manual, and labels attached to the equipment.

Operator training must be provided to ensure proper operation of equipment in compliance with instructions provided by the equipment manufacturer and the provisions of ASME B30, and proper rigging procedures for the attachment of loads to the hoist.

A safe and efficient operation of hoist requires an operator who exercises caution, common sense, and good judgment in anticipating the effects of operating the hoist. The operator must be fully alert, focused, and aware of the surroundings at all times.

The job must be strictly carried out under the good practices defined by the applicable international and national safety standards, such as ANSI, OSHAS and ASME.

This hoist must not be operated by someone who:

- Cannot read, understand and speak the language in which the security labels, ID Plate and User Manual of equipment is written.
- Does not meet the legal age requirements.
- Is under the influence of alcohol, drugs, or medication.
- Has visual or hearing impediments, or below normal reaction times.
- Has a history of or experiences seizures, mental, heart, or other illnesses that could interfere with a safe operation of the equipment.
- Has not been trained for the proper use of the hoist.
- Has not received and read the User Manual for the exact equipment.
- Has not demonstrated qualifications through a practical operation of hoist.

1.2 Handling Precautions

ALWAYS:

- Keep hoist in good condition and make sure chain is lubricated and free to operate.
- Make sure electrical connection is grounded.
- Make smooth movements; avoid sudden changes of directions.
- Check functions of hoist and trolley without any load before operation.
- De-energize equipment after using it to avoid unintentional operation.
- Keep everyone a distance of at least 1.5 times the length of chain. If load falls it can cause serious injuries and death.
- Make sure no one is beneath load.

NEVER:

- Use pulleys or other accessories that are not specifically approved for relevant hoist model.
- Hoist load with tip of hook.
- Hoist load which is not vertical to hook.
- Use hoist to pull or drag load.
- Exceed maximum capacity of hoist.

1.3 Recommended Operation



WARNING

Always carry out a complete inspection before starting the operation of the hoist.
See ASME B30.

Always let know to all personnel that crane maneuvers are about to begin!
Do not allow Unauthorized Personnel to be in the elevation area.

Start with Operational Test

1. Press (down) button lowering unloaded hook down until limit spring touches limit switch. Be sure hoist stops automatically before totally compressing spring.
2. Press (up) button hoisting unloaded hook up until limit spring touches limit switch. Be sure hoist stops automatically before totally compressing spring.
3. Test correct function of emergency stop button. When pressing button (up), (down) press emergency stop button. Ensure hoist stops immediately after pressing emergency stop switch. Hoist should not start again if any other movement button is activated.
4. Rotate emergency stop switch clockwise to original position. When it bounces back, hoist can be started again. If any of the above tests fail, unit must remain out of service, lockout/tag-out power and request maintenance authorized personnel to check circuit layout for automatic locking emergency stop switch.
5. Check lubricating condition of load chain (load chain has been lubricated before delivery, but could be dried in transportation).
Apply lubricant into chain bag to protect load chain.
6. Check direction of chain eyes. All welding points should be same direction. Hoist cannot be operated properly unless all welding chain eyes are in same line.
 - 6.1. Position hoist in vertical position to load. Before moving trolley, make sure path of hook is free from any obstacle.
 - 6.2. Lower hook near master link to hoist load and make final adjustments to secure a 90° vertical lift operation without any lateral deviation. Improper life angle may cause swinging of load.
 - 6.3. Attach hook to load link and make sure there are no people in working area. Check that no loose items can fall from load.
 - 6.4. Begin by hoisting load two inches and stop. Check brakes are fully operational and load doesn't lower while stopped. Also check load is balanced and secured. Load may have changed shape or center of gravity when suspended.
 - 6.5. To reach a desired position, movements must be smooth and continuous. Repeatedly pressing buttons may heat up motor and damage equipment.
 - 6.6. Avoid sudden directions changes. These movements may damage equipment, prematurely wear down brakes and cause accidents.



WARNING

If hoist model has double dual/speed capabilities, always start with slower speed to avoid sudden accelerations. Decelerate before completing a stop.

7. Avoid any obstacle when hoisting or traveling load.
8. Start movement of trolley and check there is no swinging of load and no obstacles in path. Stop movement and make necessary adjustments if one of these conditions is present.
9. Once desired position is reached, slowly stop trolley. Position load completely vertical to desired spot where load will be lowered.

10. Gradually lower load until it is secured on resting surface. Avoid hitting surface at high speed. If necessary, stop movement before reaching surface and gradually lower to land load.




DANGER

NEVER leave load suspended without attention of the hoist operator!

1. H3 EXPLODED VIEW AND PARTS LIST


1.1 Motor and body assembly drawing



1.2 Motor and body assembly parts list

| Item | Spare parts name | QTY | Item | Spare parts name | QTY |
|------|------------------------------|-----|------|--------------------------|-----|
| 1 | Rubber cover | 1 | 31 | Bottom plate for gearbox | 1 |
| 2 | Nut | 1 | 32 | Upper hook bearing brush | 1 |
| 3 | Motor back end locking plate | 1 | 33 | Sleeve bolt | 4 |
| 4 | Ring upper washer | 1 | 34 | Dowel pin | 2 |
| 5 | Circlip for hole | 1 | 35 | Gasket C | 1 |
| 6 | Deep groove ball bearing | 1 | 36 | Middle ware | 1 |
| 7 | Socket head cap screw | 4 | 37 | Hex screw washer | 2 |
| 8 | Spring washer | 4 | 38 | Hex screw | 2 |
| 9 | Motor Cover | 1 | 39 | Dowel pin | 2 |
| 10 | Rotor washer | 1 | 40 | Spring washer | 6 |
| 11 | Plate spring | 4 | 41 | Socket head cap bolt | 6 |
| 12 | Brake pad assembly | 1 | 42 | Gasket D | 1 |
| 13 | Brake spring | 1 | 43 | Eye Bolt | 1 |
| 14 | Brake magnet locking sleeve | 1 | 44 | Eye Bolt gasket | 1 |
| 15 | Brake magnet split ring | 2 | 45 | Gear box | 1 |
| 16 | Traction Block | 1 | 46 | Dowel pin | 1 |
| 17 | Plate spring | 1 | 47 | External tothed washer | 5 |
| 18 | Rotor assembly | 1 | 48 | Socket head cap bolt | 5 |
| 19 | Socket head cap screw | 4 | 49 | Gasket E | 1 |
| 20 | Motor cover | 1 | 50 | Electrical section cover | 1 |
| 21 | Spring-type straight pin | 2 | 51 | Spring washer | 4 |
| 22 | Gasket A | 1 | 52 | Socket head cap bolt | 4 |
| 23 | Motor Stator | 1 | | | |
| 24 | Hex nut | 4 | | | |
| 25 | Spring Washer | 4 | | | |
| 26 | Motor bottom plate | 1 | | | |
| 27 | Upper hook bearing brush | 1 | | | |
| 28 | Chain wheel case | 1 | | | |
| 29 | Sleeve | 4 | | | |
| 30 | Gasket B | 1 | | | |


1.3 Hook assembly drawing (0.5, 1, 2, 3, 5 Ton)



1.4 Hook assembly part list (0.5, 1, 2, 3, 5 Ton)

| Item | Spare parts name | QTY |
|------|------------------------------------|-----|
| 1 | Hook safety latch | 1 |
| 2 | Lower hook | 1 |
| 3 | Thrust ball bearing | 1 |
| 4 | Lower hook split ring | 2 |
| 5 | Lower hook locking sleeve | 1 |
| 6 | Socket head cap screw | 2 |
| 7 | Lower hook swivel shell | 2 |
| 8 | Chain limit spring | 1 |
| 9 | Chain | 3m |
| 10 | Self-Locking nut | 2 |
| 11 | Slotted spring | / |
| 12 | Outer hexagonal case | / |
| 13 | Lower load block case | / |
| 14 | Needle bearing | / |
| 15 | Lower load block chain wheel shaft | / |
| 16 | Lower load chain wheel | / |
| 17 | Hex-nut | / |
| 18 | Spring washer | / |
| 19 | Split pin | / |
| 20 | Hex slotted nut | / |
| 21 | Chain bolt | / |
| 22 | Chain locking block | / |


1.5 Hook assembly drawing (7.5 Ton)




1.6 Hook assembly part list

| Item | Spare parts name | QTY |
|------|------------------------------|-----|
| 1 | Hook safety latch | 1 |
| 2 | Lower Hook | 1 |
| 3 | Lower Hook swivel | 1 |
| 4 | Thrust ball bearing | 1 |
| 5 | Bearing Sheath | 1 |
| 6 | Hook nut | 1 |
| 7 | Hex-end tight set screws | 1 |
| 8 | Hex-nut | 6 |
| 9 | Spring Washer | 6 |
| 10 | Stent motherboard under | 1 |
| 11 | Chain guide | 1 |
| 12 | Chain | 9m |
| 13 | Limit Spring | 1 |
| 14 | Chain Guide body | 1 |
| 15 | Chain bolt | 1 |
| 16 | Chain locking block | 1 |
| 17 | Gasket locking block | 2 |
| 18 | Hex slotted nut | 1 |
| 19 | Split pin | 1 |
| 20 | Shaft locking block | 1 |
| 21 | Stent vice board under | 1 |
| 22 | Lower hook chain wheel shaft | 1 |
| 23 | Spring straight pins | 1 |
| 24 | Cir-clip for hole | 2 |
| 25 | Stents double nuts | 3 |
| 26 | Needle bearing | 2 |
| 27 | Guiding pulley | 1 |
| 28 | Chain wheel | 1 |
| 29 | Circlip | 2 |

1.7 Gear Box Assembly drawing




DUAL SPEEDS



1.8 Gear Box parts list

| Item | Spare parts name | QTY |
|------|----------------------------------|-----|
| 1 | Deep groove ball bearing | 1 |
| 2 | Circlip for shaft | 1 |
| 3 | Output gear | 1 |
| 4 | Deep groove ball bearing | 1 |
| 5 | Gear-gear shaft | 1 |
| 6 | Deep groove ball bearing | 1 |
| 7 | Deep groove ball bearing | 1 |
| 8 | Oil seal | 1 |
| 9 | Chain wheel | 1 |
| 10 | Oil seal | 1 |
| 11 | Output shaft assembly | 1 |
| 12 | Deep groove ball bearing | 1 |
| 13 | Bearing fixed ring | 1 |
| 14 | Deep groove ball bearing | 1 |
| 15 | Circlip for hole | 1 |
| 16 | Spring straight pins | / |
| 17 | Spring washer | / |
| 18 | Socket head cap screws | / |
| 19 | Reduction gear fixed axis | / |
| 20 | Bearing | / |
| 21 | Dual Gears | / |
| 22 | Reduction gear fixed frame | / |
| 23 | Reduction gear fixed stator | / |
| 24 | Cross Recessed Countersunk screw | / |


1.9 Chain assembly drawing



1.10 Chain assembly parts list

| Item | Spare parts name | QTY |
|------|---------------------------------|-----|
| 1 | Socket head cap screws | 2 |
| 2 | Oriented iron | 1 |
| 3 | Slotted countersunk head screw | 2 |
| 4 | Chain guide | 1 |
| 5 | Pulley shaft | 1 |
| 6 | Oriented pulley | 1 |
| 7 | Spring washer | 4 |
| 8 | Socket head cap screws | 4 |
| 9 | Split pin | 1 |
| 10 | Limit switches connection shaft | 1 |
| 11 | Middle pin axis | 1 |
| 12 | Guide frame middle pin | 1 |
| 13 | Guide frame assembly | 1 |
| 14 | Chain bag | 1 |
| 15 | Limit spring | 1 |
| 16 | Socket head cap screws | 2 |
| 17 | Chain split ring | 2 |
| 18 | Spring washer | 2 |
| 19 | Chain | 3m |
| 20 | Nut | 2 |
| 21 | Spring washer | 2 |


1.11 Gear Box Assembly drawing



1.12 Gear Box parts list

| Item | Spare parts name | QTY |
|------|--|-----|
| 1 | Control Switch | 1 |
| 2 | Tightrope Buckle | 1 |
| 3 | Round Buckle | 2 |
| 4 | Spring Washer | 4 |
| 5 | Wiring fixed ring accessories | 1 |
| 6 | Cable sheath | 1 |
| 7 | Fixed wiring ring | 1 |
| 8 | Connecting shaft assembly for control switch | 1 |
| 9 | Round cross screw M6*10 | 2 |
| 10 | Electrical Installation Plate | 1 |
| 11 | Spring washer Ø6 | 4 |
| 12 | Round cross screw M6*10 | 4 |
| 13 | Reverse Bracket B | 1 |
| 14 | Spring washer Ø4 | 5 |
| 15 | Round cross screw M4*10 | 5 |
| 16 | Transformer | 1 |
| 17 | Electromagnetic contactor | 2 |
| 18 | Mechanical Linkage | 1 |
| 19 | Terminal Block | 1 |
| 20 | Reverse Phase Protector | 1 |
| 21 | Round cross screw M4*15 | 2 |
| 22 | Fixed Rail | 1 |


1.13 Electric Trolley assembly drawing



1.14 Electric Trolley assembly parts list

| Item | Spare parts name | QTY | Item | Spare parts name | QTY |
|------|-------------------------------|-----|------|--------------------------------------|-----|
| 1 | Socket head cap screws M6*20 | 4 | 33 | Toothed driving wheel | 2 |
| 2 | Spring washer Ø6 | 4 | 34 | Self-locking nut | 1 |
| 3 | Motor back end cover | 1 | 35 | Adjusting spacer | 8 |
| 4 | Deep groove ball bearing 6202 | 1 | 36 | Split pin | 1 |
| 5 | 5-Brake Assembly | 1 | 37 | Trolley shaft | 1 |
| 6 | Rubber Circlip | 1 | 38 | Socket head cap screw | 8 |
| 7 | Socket head cap screws | 4 | 39 | Spring washer | 8 |
| 8 | Spring washer | 4 | 40 | Auxiliary wheel shaft | 4 |
| 9 | Motor Cover | 1 | 41 | Auxiliary wheel bracket | 4 |
| 10 | Motor Stator | 1 | 42 | Trolley subplate assembly | 1 |
| 11 | Brake Spring | 1 | 43 | Gasket | 4 |
| 12 | Rotor Assembly | 1 | 44 | Electric control case cover assembly | 1 |
| 13 | Deep groove ball bearing | 1 | 45 | Spring washer | 4 |
| 14 | Motor bottom plate | 1 | 46 | Socket head cap screw | 4 |
| 15 | Motor bottom plate gasket | 1 | 47 | Wire connection bracket | 1 |
| 16 | Circlip for shaft | 1 | 48 | Cross Recess Head screw | 4 |
| 17 | Gear | 1 | 49 | Electric control case cover assembly | 1 |
| 18 | Socket head cap screw | 4 | 50 | Electric control case cover | 1 |
| 19 | Spring washer | 4 | 51 | Spring washer | 4 |
| 20 | Gear box | 1 | 52 | Socket head cap screw | 4 |
| 21 | Spring washer | 4 | 53 | Socket head cap screw | 1 |
| 22 | Socket head cap screws | 2 | 54 | Trolley shaft dowel pin | 1 |
| 23 | Socket head cap screws | 2 | 55 | Circlip for shaft | 4 |
| 24 | Circlip | 1 | 56 | Trolley wheel washer | 4 |
| 25 | Deep Groove ball bearing | 2 | 57 | Trolley wheel | 2 |
| 26 | Circlip for hole | 1 | 58 | Deep groove ball rolling bearing | 4 |
| 27 | Slide plate gasket | 1 | 59 | Circlip for hole | 4 |
| 28 | Slide plate | 1 | 60 | Auxiliary wheel bracket gasket | 4 |
| 29 | Spring Washer | 4 | 61 | Trolley auxiliary wheel | 4 |
| 30 | Socket head cap screw | 4 | | | |
| 31 | Trolley main plate assembly | 1 | | | |
| 32 | Spline gear shaft | 1 | | | |

1.15 Trolley assembly drawing




1.16 Trolley assembly parts list

| Item | Spare parts name | QTY |
|------|-----------------------------|-----|
| 1 | Circlip for shaft | 4 |
| 2 | Trolley wheel washer | 4 |
| 3 | Trolley wheel | 4 |
| 4 | Deep groove ball bearing | 4 |
| 5 | Circlip for hole | 4 |
| 6 | Trolley main plate assembly | 1 |
| 7 | Self-locking nut | 1 |
| 8 | outer hexagonal screw | 1 |
| 9 | Trolley shaft | 1 |
| 10 | Adjusting spacer | 8 |
| 11 | Trolley subplate assembly | 1 |
| 12 | Split pin | 1 |
| 13 | Trolley shaft dowel pin | 1 |

2. H4 EXPLODED VIEW AND PARTS LIST


2.1 Motor and body assembly drawing



2.2 Motor and body assembly parts list

| Item | Spare parts name | QTY | Item | Spare parts name | QTY |
|------|------------------------------|-----|------|--------------------------------|-----|
| 1 | Socket head cap screw | 4 | 31 | Chain wheel case | 1 |
| 2 | Fan cover | 1 | 32 | Gasket B | 1 |
| 3 | Washer for shaft | 1 | 33 | Sleeve | 1 |
| 4 | Fan blade | 1 | 34 | Upper hook bearing brush | 1 |
| 5 | Nut | 1 | 35 | Sleeve bolt | 4 |
| 6 | Motor back end locking plate | 1 | 36 | Gasket C | 1 |
| 7 | Ring upper washer | 1 | 37 | Dowel pin | 4 |
| 8 | Circlip for hole | 1 | 38 | Middle Ware | 1 |
| 9 | Deep groove ball bearing | 1 | 39 | Hex screw washer | 2 |
| 10 | Socket head cap screw | 4 | 40 | Hex screw | 2 |
| 11 | Spring washer | 4 | 41 | Socket head cap bolt | 6 |
| 12 | Motor cover | 1 | 42 | Gasket D | 1 |
| 13 | Rotor washer | 1 | 43 | Gearbox | 1 |
| 14 | Plate spring | 4 | 44 | External toothed washer | 4 |
| 15 | Brake pad assembly | 1 | 45 | Socket head cap bolt | 4 |
| 16 | Brake spring | 1 | 46 | Cover belt | 1 |
| 17 | Brake magnet locking sleeve | 1 | 47 | Cross Recess Head Screw | 2 |
| 18 | Brake magnet split ring | 2 | 48 | Gasket E | 5 |
| 19 | Traction block | 1 | 49 | Electrical section cover | 1 |
| 20 | Plate spring | 1 | 50 | Socket head cap bolt | 4 |
| 21 | Rotor assembly | 1 | 51 | Cover plate | 1 |
| 22 | Motor Stator | 4 | 52 | Slotted countersunk head screw | 4 |
| 23 | Motor cover | 1 | | | |
| 24 | Socket head cap screw | 4 | | | |
| 25 | Spring-Type straight pin | 2 | | | |
| 26 | Gasket A | 1 | | | |
| 27 | Upper | 2 | | | |
| 28 | Hex nut | 4 | | | |
| 29 | Spring washer | 4 | | | |
| 30 | Motor bottom plate | 1 | | | |


2.3 Hook assembly drawing (0.5, 1, 2, 3, 5 Ton)



2.4 Hook assembly part list (0.5, 1, 2, 3, 5 Ton)

| Item | Spare parts name | QTY |
|------|------------------------------------|-------|
| 1 | Hook safety latch | 1 |
| 2 | Lower hook | 1 |
| 3 | Thurst ball bearing | 1 |
| 4 | Lower hook split ring | 2 |
| 5 | Lower hook locking sleeve | 1 |
| 6 | Socket head cap screw | 2 |
| 7 | Lower hookswivel cover | 2 |
| 8 | Cahin limit spring | 1 |
| 9 | Chain | 3.5 m |
| 10 | Self-locking nut | 2 |
| 11 | Slotted spring pins | / |
| 12 | Outer Hexagonal cover | / |
| 13 | Lower load block cover | / |
| 14 | Needle bearing | / |
| 15 | Lower load block chain wheel shaft | / |
| 16 | Lower load chain wheel | / |
| 17 | Hexnut | / |
| 18 | Spring washer | / |
| 19 | Split pin | / |
| 20 | Hex slotted nut | / |
| 21 | Chain bolt | / |
| 22 | Chain locking block | / |


2.5 Hook assembly drawing (7.5 Ton)



2.6 Hook assembly part list

| Item | Spare parts name | QTY |
|------|------------------------------|--------|
| 1 | Hook safety latch | 1 |
| 2 | Lower Hook | 1 |
| 3 | Hook to undertake block | 1 |
| 4 | Thrust ball bearing | 1 |
| 5 | Bearing sheath | 1 |
| 6 | Hook nut | 1 |
| 7 | Hex-end tight set screws | 1 |
| 8 | Hexnut | 6 |
| 9 | Spring Washer | 6 |
| 10 | Stent motherboard under | 1 |
| 11 | Chain guide | 1 |
| 12 | Chain | 10.5 m |
| 13 | Limit Spring | 1 |
| 14 | Guide chain body | 1 |
| 15 | Chain bolt | 1 |
| 16 | Chain locking block | 1 |
| 17 | Locking gasket block | 2 |
| 18 | Hex lotted nut | 1 |
| 19 | Split pin | 1 |
| 20 | Locking shaft block | 1 |
| 21 | Stent vice board under | 1 |
| 22 | Lower hook chain wheel shaft | 1 |
| 23 | Spring straight pins | 1 |
| 24 | Circlip for hole | 2 |
| 25 | Stents double nut | 3 |
| 26 | Deedle bearing | 2 |
| 27 | Guiding pulley | 1 |
| 28 | Chain wheel | 1 |
| 29 | Circlip | 2 |


2.7 Gear Box Assembly drawing



2.8 Gear Box parts list

| Item | Spare parts name | QTY |
|------|------------------------------|-----|
| 1 | Deep groove ball bearing | 1 |
| 2 | Shaft circlip | 1 |
| 3 | Output gear | 1 |
| 4 | Torque nut | 1 |
| 5 | Oil seal fixing sleeve | 1 |
| 6 | O ring | 1 |
| 7 | Deep groove ball bearing | 1 |
| 8 | Spring plate fixing sleeve | 1 |
| 9 | Disc Spring plate | 2 |
| 10 | Braking Plate | 2 |
| 11 | Intermediate gear | 1 |
| 12 | Gear fixing plate | 1 |
| 13 | Gear shaft | 1 |
| 14 | Deep groove ball bearing | 1 |
| 15 | Deep groove ball bearing | 1 |
| 16 | Oil seal | 1 |
| 17 | Chain wheel | 1 |
| 18 | Oil seal | 1 |
| 19 | Deep groove ball bearing | 1 |
| 20 | Output shaft assembly | 1 |
| 21 | Deep groove ball bearing | 1 |
| 22 | Circlip for hole | 1 |
| 23 | Motor base plate spare parts | 1 |


2.9 Chain assembly drawing



2.10 Chain assembly parts list

| Item | Spare parts name | QTY |
|------|----------------------------------|-------|
| 1 | Socket head cap bolt | 2 |
| 2 | Spring washer | 2 |
| 3 | Hex nut | 2 |
| 4 | Slotted counter sunk head screws | 2 |
| 5 | Oriented iron | 1 |
| 6 | Chain guide | 1 |
| 7 | Pulley Shaft | 1 |
| 8 | Oriented pulley | 1 |
| 9 | Spring washer | 2 |
| 10 | Socket head cap screws | 2 |
| 11 | Limit switch spring | 1 |
| 12 | Guide limited pin | 1 |
| 13 | Elastic cylindrical pin | 1 |
| 14 | Limit guide frame | 1 |
| 15 | Chain bag | 1 |
| 16 | Bumper block | 1 |
| 17 | Socket head cap screws | 2 |
| 18 | Spring washer | 2 |
| 19 | Chain split spring | 2 |
| 20 | Chain | 3.5 m |


2.11 Gear Box Assembly drawing



2.12 Gear Box parts list

| Item | Spare parts name | QTY |
|------|---------------------------------|-----|
| 1 | Control Switch | 1 |
| 2 | Tightrope buckle | 1 |
| 3 | Round cross screw M6x12 | 2 |
| 4 | Spring washer | 4 |
| 5 | Wiring fixed ring accessories | 1 |
| 6 | Cable sheath | 1 |
| 7 | Fixed wiring ring | 1 |
| 8 | Control switch connection shaft | 1 |
| 9 | Round cross screw M6x10 | 2 |
| 10 | Electrical installation plate | 1 |
| 11 | Spring washer $\varnothing 6$ | 4 |
| 12 | Round cross screw M6x15 | 4 |
| 13 | Reverse bracket B | 2 |
| 14 | Spring washer $\varnothing 4$ | 5 |
| 15 | Round cross screw M4x10 | 5 |
| 16 | Transformer | 1 |
| 17 | Electromagnetic contactor | 2 |
| 18 | Mechanical linkage | 1 |
| 19 | Terminal block | 1 |
| 20 | Reverse polarity protector | 1 |
| 21 | Round cross screw M4x15 | 2 |
| 22 | Fixed rail | 1 |


2.13 Electric Trolley assembly drawing



2.14 Electric Trolley assembly parts list

| Item | Spare parts name | QTY | Item | Spare parts name | QTY |
|------|-------------------------------|-----|------|----------------------------------|-----|
| 1 | Socket head cap screws M6x20 | 4 | 33 | Toothed driving wheel | 2 |
| 2 | Spring washer Ø6 | 4 | 34 | Self-locking nut | 1 |
| 3 | Motor back end cover | 1 | 35 | Adjusting spacer | 8 |
| 4 | Deep groove ball bearing 6202 | 1 | 36 | Split pin | 1 |
| 5 | Brake Assembly | 1 | 37 | Trolley shaft | 1 |
| 6 | Rubber Clip | 1 | 38 | Socket head cap screw | 8 |
| 7 | Socket head cap screws | 4 | 39 | Spring Washer | 8 |
| 8 | Spring washer | 4 | 40 | Auxilliary wheel shaft | 4 |
| 9 | Motor Shell | 1 | 41 | Auxilliary wheel bracket | 4 |
| 10 | Motor Stator | 1 | 42 | Trolley subplate assembly | 1 |
| 11 | Brake Spring | 1 | 43 | Gasket | 4 |
| 12 | Rotor Assembly | 1 | 44 | Electric control case assembly | 1 |
| 13 | Deep groove ball bearing | 1 | 45 | Spring washer | 4 |
| 14 | Motor bottom plate | 1 | 46 | Socket head cap screw | 4 |
| 15 | Motor bottom plate gasket | 1 | 47 | Wire connection bracket | 1 |
| 16 | Shaft Circlip | 1 | 48 | Cross recess head screw | 4 |
| 17 | Gear | 1 | 49 | Electric control case gasket | 1 |
| 18 | Socket head cap screw | 4 | 50 | Electric control case | 1 |
| 19 | Spring washer | 4 | 51 | Spring Washer | 4 |
| 20 | Gear box | 1 | 52 | Socket head cap screw | 4 |
| 21 | Spring washer | 4 | 53 | Socket head cap screw | 1 |
| 22 | Socket head cap screw | 2 | 54 | Trolley shaft dowel pin | 1 |
| 23 | Socket head cap screw | 2 | 55 | Circlip for shaft | 4 |
| 24 | Circlip | 1 | 56 | Trolley wheel washer | 4 |
| 25 | Deep Groove ball bearing | 2 | 57 | Trolley wheel | 2 |
| 26 | Circlip for hole | 1 | 58 | Deep groove ball rolling bearing | 4 |
| 27 | Slide plate gasket | 1 | 59 | Circlip for hole | 4 |
| 28 | Side plate | 1 | 60 | Auxiliary wheel bracket gasket | 4 |
| 29 | Spring washer | 4 | 61 | Trolley auxiliary wheel | 4 |
| 30 | Socket head cap screw | 4 | 62 | Trolley auxiliary wheel washer | 8 |
| 31 | Trolley main plate assembly | 1 | 63 | Deep groove ball bearing | 4 |
| 32 | Spline gear shaft | 1 | | | |

2.15 Trolley assembly drawing









1.16 Trolley assembly parts list


| Item | Spare parts name | QTY |
|------|-----------------------------|-----|
| 1 | Circlip for shaft | 4 |
| 2 | Trolley wheel washer | 4 |
| 3 | Trolley wheel | 4 |
| 4 | Deep groove ball bearing | 4 |
| 5 | Circlip for hole | 4 |
| 6 | Trolley main plate assembly | 1 |
| 7 | Self-locking nut | 1 |
| 8 | Outer hexagonal screw | 1 |
| 9 | Trolley shaft | 1 |
| 10 | Adjusting spacer | 8 |
| 11 | Trolley subplate assembly | 1 |
| 12 | Split pin | 1 |
| 13 | Trolley shaft dowel pin | 1 |



1. OPERATION

1.1. Periodic Inspection

| Items | Inspection Method | Standards | Correction |
|---|---|--|--|
| Marks such as name-plates, labels etc. | Visual check | Clear marks and no peeling | Proceed with cleaning, repairing and replacing. Record serial number for replacing |
| Deformation or damage of body parts | Visual check  | No remarkable deformation, damage, defect or chap | Replace parts which are deformed, damaged, and defective |
| Bolts, nuts, and cutters loose or falling off | Visual and tool check | <ul style="list-style-type: none"> - Correct installation -A loose bolt will cause equipment failure - Ensure proper installation to avoid death or serious injury | Precise installation |

| Items | Inspection Method | Standards | Correction |
|-----------------------------|--|---|---------------------|
| Extent of pitch | Check by chain measurement tool |  | |
| Attrition of chain diameter | Check with chain measurement tool |  | |
| Deformation, damage, wind | <p>Visual check</p> <p>Damage Chap</p>  <p>Confirm chain is not stuck to welding spatters by visually inspecting it.</p> | <ul style="list-style-type: none"> - No deep cut - No Deformation - No deformation - No Wind -No Chap | Replace load chains |
| Rust and corrosion | Visual check | No remarkable rust and corrosion | Replace load chains |
| Distortion | Visual check | <p>No distortion due to bottom block rollover of double chain models</p>  | Correct distortion |
| Oil supply | Visual check | <p>Adequate supply of oil</p>  | Oiling |

| Items | Inspection Method | Standards | | | Correction |
|-----------------------|--|---|------------------|--------|---|
| Limit switch | Check by pushing button | Operate until upper and lower limit cause automatic motor shutdown | | | Replace limit switch, disassemble and clean limit lever |
| Movement confirmation | Check by pushing button | -Load chain can roll up easily -Motor shutdown immediately when operation stops -All movements shutdown when E-stop button pushed -Other buttons cannot cause movement when pushing the E-stop button -All movements return to normal operation when E-STOP button relieved | | | |
| Brake | Check by pushing button | Brake quickly activates and operation of bottom hook immediately stops (amount of movement of the load chain is within 2 to 3 rings) | | | |
| Chain Spring | Visual inspection and measure dimensions | Chain | Length of spring | | Replace chain spring  |
| | | | Standard | Limits | |
| | | Ø6.3 | 145 | 140 | |
| | | Ø7.1 | 145 | 140 | |
| | | Ø10.0 | 135 | 129 | |
| | Ø11.2 | 160 | 152 | | |

| Items | Inspection Method | Standards | Correction | | | | | | |
|-----------------------------------|---|---|---|----|-----|-----|-----|----|--|
| Attrition and opening of the hook | Visually check and with vernier caliper tool  | No remarkable opening or attrition | | | | | | | |
| | | Load | a | b | c | d | e | g | |
| | | 0.3 -0.5 | 27 | 18 | 25 | 17 | 35 | 28 | |
| | | 1 | 34 | 24 | 30 | 24 | 42 | 32 | |
| | | 2 | 46 | 29 | 39 | 30 | 49 | 40 | |
| | | 3 | 56 | 35 | 49 | 34 | 59 | 48 | |
| | | 5 | 67 | 43 | 67 | 44 | 60 | 48 | |
| | | 7.5 - 10 | 82 | 55 | 80 | 48 | 85 | 80 | |
| | | 15 | 110 | 78 | 120 | 80 | 120 | 90 | |
| 20 - 25 | 142 | 95 | 155 | 98 | 150 | 115 | | | |
| Deformation, damage and corrosion | Visual check | No remarkable deformation, harmful damage and corrosion | Replace hook | | | | | | |
| Hook safety block | Visual inspection, fold and unfold actions | -Can exactly fold inside the hook -No deformation Dangerous -Do not use hook if safety block is loosening Improper use will lead to death or serious injury | Replace hook safety block  | | | | | | |
| Hook movements (rotate) | Visual inspection and manual rotation | -No remarkable space between bottom supporting and top -equal at right and left -easy to rotate 360° | Replace hook | | | | | | |

1.3. During Operation:

| Symptoms | | Main Cause | Correction | |
|--|-----------------------------------|--|------------------------------|--------------------------|
| Hoist does not operate | Brake is inaudible | Excessive voltage | Power | |
| | | | Power supply | |
| | | Operating circuit break-off, electric parts over-heating | Internal wiring | |
| | | | Contactors | |
| | | | Transformer | |
| | | | Up/Down limit switch | |
| | Contactors is audible | Power circuit break-off, overheating motor, brake | Button switch | |
| | | | Motor | |
| | | | Brake | |
| | | | Internal wiring | |
| Brake is audible | Drive overheating, broken bearing | Contactors (junction fusing) | | |
| | | Gear | | |
| Operates without load only | Unable to lift (motor roar) | Default phase (single phase operation) | Bearing | |
| | | | Power | |
| Feed power | | | | |
| Motor | | | | |
| Unintended reaction from button | Slow lifting | Low voltage | Contactors (junction fusing) | |
| | | | Feed power | |
| | Inverse reaction from button | Wrong phase sequence wiring | Incorrect signal wiring | Feed power |
| | | | | Internal wiring |
| | No reaction after pressing button | Circuit wire break | Electric installation parts | Button switch |
| | | | | Internal wiring |
| | | Electric installation parts | Button switch | Contactors |
| | | | | Up/Down limit switch |
| | | | | Contactors |
| | | | | Brake |
| | | | | Feed power |
| | | | | Internal wiring |
| | | | | Button switch |
| | | | | Load chain |
| | | | | Load pulley, bare pulley |
| | | | | Gear |
| Bearing | | | | |
| Noise of brake | Running (grating) | Drag | Brake | |
| | Stop | Wear of friction plate | Brake | |
| Abnormal noise of rail curve (grating) | | Obstruction of orbit/wheel | Operation of trolley | |

| Fault | | Major Cause | Check Items |
|---|--|---|----------------------------|
| Does not move horizontally | | Rail declining | Trolley movement |
| | Electric trolley /manual trolley | Inclined pull (wheel is lifting) | Trolley movement |
| | Electric trolley /manual trolley | Gear occlusion problem | Trolley movement |
| | Electric trolley /manual trolley | Brake fastening | Trolley movement |
| | Electric trolley | Electric faults | Trolley movement |
| Irregular movement and noise | Electric trolley /manual trolley | Rail & wheel interference | Trolley movement |
| | | Side wheel lacks oil | |
| | | Uneven wheel wear | |
| | | Wheel deformation | |
| | | Rail deformation, wear | |
| | | Bearing wear | |
| | | Brake wear | |
| Hook | | Deformation | Hook |
| Load chain | | Wear, extension, deformation | Load chain |
| Electric shock upon touching machinery body or control switch | | Equipment not properly grounded | Proper electric connection |
| Does not operate in non-load state | Brake inaudible | Supply power | Supply power voltage |
| | | Operating circuit break-off, electric parts overheating | Cables |
| | | | Internal wiring |
| | | | Transformer |
| | | | Electrical relay |
| | | | Limit switch |
| | | Push button switch | |
| | Braking interval too large or small. | Motor | |
| | Calibrate brake | | |
| | Tripping as motor overheats | Thermal protector | |
| Brake audible | Bearing burning out, driving component wear | Replace brake bearing | |
| | | Bearing | |
| Slow load operation | Voltage drop | Feed cable | |
| Low and high speed status not operating or working slow | Low voltage | Supply power | |
| | Voltage drop | Feed cable | |
| Movement does not correspond with switch button | Movement did not correspond with switch button | Motor wires connected | Motor |
| | | Connection error | Internal wiring |
| | | | Push button switch |
| | Switch button did not work | Operating circuit break-off | Internal wiring |
| | | | Push button switch |
| | Electrical installation error | Limit switch | |

| Condition | Reason | Action | Cause | Correction |
|--------------|-------------------------|--------------|-----------------------|------------------------------|
| No operation | Abnormal supply voltage | Power supply | Improper power supply | Check power supply regularly |

Power Cable

| Condition | Reason | Action | Cause | Correction |
|---|-----------------------------|--|--------------------------------------|--|
| No operation | Wire break | Repair or change cable if broken | Strong force exerted | Firmly fix on cable support or other equipment |
| | | | (2 or more) | Use anti-vibration cable in movable part. |
| | | | Twisted, knotted | Straighten twists and knots |
| | | | Interference with other equipment | Use fixed cable and avoid outside interference |
| | Overheating | Check cables, exchange if overheating | Temperature rise due to off-capacity | Adopt the proper cable |
| | | | Binding cable used | Do not use binding cable |
| Starting slow or no operation | Off-capacity | Check cable diameter, replace cable if diameter is too small | Voltage drop | Adopt proper cable |
| Operation only in free load (single phase) | 1 wire break or overheating | Refer to above break or overheating item | | |
| Movement did not correspond with switch button (opposite) | Power line connection error | Replace wires | Wiring assembly error | Connect wire as per wiring diagram |

Motor

| Condition | Reason | Action | Cause | Correction |
|--|-----------------------------------|--|--|---|
| No operation | Coil burning (above 2 phase) | Measure phase resistance value; change motor if value is infinite. | Excessive current caused by high or low voltage | Operate under rated voltage |
| | | | Excessive current caused by overload | Operate under rated voltage |
| | | | Beyond short-term rating and intermittent cycle rating | Short-term rating, intermittent cycle rating, operate under rated voltage |
| | | | | Avoid over-operation |
| | | | Excessive current caused by brake | Refer to brake |
| | Lead wire break (above 2 phase) | Measure phase resistance value; change motor if value is infinite. | Lead wire broken in assembly | Change motor coil |
| Vibration, drop | | | Avoid excessive bumping in usage | |
| Operation only in free load (single phase state) | Coil burning (1 phase only) | Measure phase resistance value; change motor if value is infinite | Poor electric isolation | Ensure foreign matter does not enter motor |
| | Leading wire break (1 phase only) | Measure phase resistance value; change motor if value is infinite | Leading wire break in assembly | Change motor coil |
| | | | Vibration, drop | Avoid excessive bumping |

Brake

| Condition | Reason | Action | Cause | Correction | |
|---------------------|---|--|---|---|---|
| No operation | Braking coil burning | Measure brake phase resistance value; change brake if value is infinite. | Excessive current caused by high or low voltage | Operate under rated voltage | |
| | | | | Avoid over-operation | |
| | | | Excessive current caused by overload | Operate under rated voltage | |
| | | | | Confirm short-term rating, intermittent cycle rating, operate under rated voltage | |
| | | | | Excessive current caused by operation in single phase state | Stop immediately if unable to lift load in single phase |
| | Friction plate beyond brake magnetism scope | Measure brake clearance, replace if space is over usage limit | | | Avoid over-operation |
| | Broken brake wire | Ensure wire is connected, replace if disconnected | Lead wire damaged during assembly | | Replace coil brake |
| | Improper connection of brake wire terminal | Replace insert terminal when loose | Assembly error | | Proper connection in assembly |
| | Rust | Replace brake if rust present | | Exposure to water in storage | Ensure dry storage |
| | | | Condensation | Monitor usage environments | |
| Friction plate wear | Measure brake clearance, replace if space is over use limit | | | Avoid over-operation | |

Inside Wiring

| Condition | Reason | Action | Cause | Correction |
|--------------|---|--|----------------------------------|--|
| No operation | Break | Check cable, repair if wire break | Vibration, drop | Avoid excessive bumping in usage |
| | | | Leading wire damaged in assembly | Change motor coil |
| | | Check connector, repair if wire break | Connector not properly set | Press by appropriate tool |
| | Wiring error | Refer to wiring diagram, ensure properly connected | Wiring error | Refer to wiring diagram, ensure properly connected |
| | Connector screws loose | Fastening | Improper fastening | Ensure effective fastening |
| | (overheating) | | Vibration, drop | Avoid excessive bumping in usage |
| | Connector, insert terminal improper combination | Proper combination | Bad combination during assembly | Ensure combination is effective |

Transformer

| Condition | Reason | Action | Cause | Correction |
|------------------------------|---------------------|--|---|-------------------------------------|
| No operation (contractor) | Coil burning, break | Measure coil resistance value; Change transformer if value infinite | Excessive voltage | Operate under rated voltage |
| | | | | Avoid over-operation |
| | | | Excessive current caused by contractor | Refer to contactor items |
| | | | Vibration, drop | Avoid excessive bumping in usage |
| | Wire break | Check leading wire, repair or change transformer if wire | Vibration, drop | Avoid excessive bumping in usage |

Contactor & Electric Reply

| Condition | Reason | Action | Cause | Correction |
|---------------------|------------------------------|---|--|-------------------------------------|
| Non-stop activation | Junction welding burn out | Change contactor if continuous welding or burn out. For electric reply, visual inspection of junction | | Do not over-operate |
| | | | Excessive voltage (Excessive current) | Operate under rated voltage |
| | | | Excessive current due to overload | Operation under rated voltage |
| No operation | Coil burning | Measure coil resistance value. Change coil if value infinite. | | Avoid over-operation |
| | | | Excessive voltage | Operate under rated voltage |
| | | | Vibration due to low voltage (Starting current added continuous) | Operate under rated voltage |
| | | Replace contactor if action is not smooth. For electric reply, visual inspection for part breakage | Vibration, drop | Avoid excessive bumping in usage |

Limit switch

| Condition | Reason | Action | Cause | Correction |
|--|---------------------------|---|--|---|
| No operation (Contactor) | Contact fused | Operate limit switch. Check continuity of contactor, replace if result is negative | Limit switch overuse | Avoid overuse of switch |
| | Wire break | Inspect cable, change if wire breakage or replace limit switch | Vibration, drop | Avoid excessive bumping in usage |
| | Moveable parts rusting | Check movable parts such as limit lever. Remove if rusty or replace if adhesive | Set in Up/Down limit for long time | Do not set in Up/Down limit |
| Motor did not stop upon reaching upper and lower limit | Contact welded | Operate limit switch. Check continuity of contactor, replace if does not open | Limit switch used frequently | Avoid overuse of limit switch |
| | Rusting of moveable parts | Check movable parts such as limit lever. Remove if rusty or replace if adhesive | Infrequent usage; use in moist environments. | Regular inspection |
| | Wiring error | Reference wiring diagram. If limit switch cable is properly connected, it is inversely connected. Swap 2 wire power cords | Wiring error | Properly connect wire power cords as per wiring diagram |

Push button switch

| Condition | Reason | Action | Cause | Correction |
|---|-----------------------------|---|--------------------------------|---|
| No operation (Contactor) | Emergency button is pressed | Turn button right to recover | Emergency button not reset | Read User Manual before usage |
| | Switch gear fault | Conduction contacts, replace switch if off | Vibration, drop | Avoid excessive bumping in usage |
| | Wiring break | Check if button cable is correctly connected to switch device. Repair if broken | Vibration, drop | Avoid excessive bumping in usage |
| | Terminal screw loose | Tighten screw | Vibration, drop | Avoid excessive bumping in usage |
| | Button cable wire break | Replace cable or button cable when wire break | Cable coating damaged | Avoid contact with other equipment during operation |
| Faulty installation | | | Install protection line firmly | |
| Action does not correspond with display | Wiring error | Reference wiring diagram. If limit switch cable is properly connected, it is inversely connected. Swap 2 wire power cords | Wiring error | Properly connect wire power cords as per wiring diagram |
| Operation continues upon button release | Faulty switch gear part | Replace switch if not smooth. | Vibration, drop | Avoid excessive bumping in usage |

Electric shock

| Condition | Reason | Action | Cause | Correction |
|--|---------------------------------|--|---------------------------------|---|
| Electric shock upon touching machinery or control switch | Equipment not properly grounded | Measure earth resistance. If below 100Ω assemble ground wire | Improper ground wire connection | Firmly connect ground wire |
| | | | Ground wire bad connection | Assemble carefully to prevent loose screw |
| | | | Cable break | Do not apply excessive force on cable |
| | Dampness/ water | Clean, use once dry | Wet hands | Do not operate with wet hands |

Hook

| Condition | Reason | Action | Cause | Correction |
|-----------------------------|-------------------------|--|---|---|
| Hook mouth open | Hook deformation | Replace hook if deformation is beyond permitted range. | Overload | Operate under rated voltage |
| | | | Lifting (hook connected with grounded object) | Do not lift grounded objects. |
| | | | Load hanging on hook head; hook pull horizontal | Lifting load properly with hook |
| | | | Hanger suspension errors | Lifting angle must be controlled within 120 ° |
| | | | Load size exceeds rated hook | Using proper hook |
| | | | Chain wrapped around load | Do not wrap chain |
| Hook twist | | | | |
| Head hook improper rotating | Bearing rust, corrosion | Hand rotation; maintain or replace if experiencing difficulty rotating | Inadequate grease lubricant; corrosion | Apply grease lubricant regularly; prevent hook contamination of chemical agents |
| | Bearing damage | | Dust | Prevent foreign matter from entering head |

Load chain

| Condition | Reason | Action | Cause | Correction |
|--|--|---|---|---|
| Chain is twisted | Bottom hook up-turned | Reset hook | Bottom hook rotation during usage | Check hook state before operation |
| | Chain twist in machinery body | Reassemble chain guide and load chain | Improper assembly | Ensure proper assembly |
| Limit switch suddenly activated while lowering | Chain is twisted or knot in chain bag | Confirm chain bag capacity (chain bag nameplate) replace with larger one if capacity insufficient | Chain bag inadequate capacity | Confirm lifting height and chain bag capacity |
| Crackling sound | Chain is damaged | Measure wear of chain link diameter. Replace if reaching wear limit | Long-term operation with insufficient lubrication | Apply grease lubricant regularly |
| Irregular sound from springs (cracking sound) | Wear of link part | Measure diameter on wear of chain, and replace when at wear limit | Excessive operation | Avoid excessive operation |
| | | | Overload | Use under rated load |
| | | | Incline pull | Ensure proper pull direction |
| | Wear of load pulley and empty pulley | Refer to load pulley and empty pulley | | |
| Extension of pitch | Measure pitch and replace when exceeding limit | Overload | Use under rated load | |
| Irregular sound | Damage or deformation on chain surface | Replace when obvious damage and deformation occur | Use under transition situation | Use under models with multiple chain |
| | Mark on chain surface | | Chain used improperly | Ensure proper assembly |
| | | | Damaged by other equipment | Monitor surrounding environment throughout usage to avoid collisions |
| Discoloration | Rust, corrosion | Apply lubricants and replace when obvious rust and corrosion occurs | Lubricant exhausted | Apply lubricating oil regularly |
| | | | Exposure to water | Use in dry places |
| | | | Influenced by seawater or chemical agent | Inform us if used in special circumstances to safeguard range |
| Load chain fractured | Reaching service life | Check chain, replace if differing from benchmark specifications | Mechanical life | Operate correctly and manage properly including inspection before usage and regular check-ups |

Chain Wheel

| Condition | Reason | Action | Cause | Correction |
|----------------|---------------------|---|---|---------------------------------|
| Improper noise | Wear of chain wheel | Check wear degree on chain, wheel slot, and load chain. Replace if badly worn | Long-term operation with insufficient lubrication | Apply lubricating oil regularly |
| | | | Excessive operation | Avoid excessive operation |
| | | | Overload | Use under rated load |
| | | | Incline pull | Avoid incline pull |

Load pulley and empty pulley

| Condition | Reason | Action | Cause | Correction |
|---|----------------|---|---|---------------------------------|
| Irregular sound from springs (cracking sound) | Wear of pulley | Measure slot edge thickness and load chain, replace if badly worn | Long-term operation with insufficient lubrication | Apply lubricating oil regularly |
| | | | Excessive operation | Avoid excessive operation |
| | | | Overload | Use under rated load |
| | | | Incline pull | Avoid incline pull |

Chain Guide

| Condition | Reason | Action | Cause | Correction |
|-------------------|--------------------------------------|--|--------------|--------------------|
| Increased shaking | Wear of chain guide and guide pulley | Measure benchmark size and load chain, replace if badly worn and limit size exceeded | Incline pull | Avoid incline pull |

Chain Wheel, Junction Part

| Condition | Reason | Action | Cause | Correction |
|----------------------|----------------|---|---|--|
| Unable to lift loads | Wear, breakage | Replace when obvious wear or breakage occur | Long-term operation with insufficient lubrication | Apply lubricating oil and inspect annually |
| | | | Long-term operation with insufficient lubrication (joint part of motor shaft) | Apply lubricating oil and inspect annually |
| Irregular operation | Wear, breakage | | Limit switch used too frequently | Avoid excessive use of limit switch |

Bearing

| Condition | Reason | Action | Cause | Correction |
|----------------------|----------|-----------------|------------------------------------|--|
| Unable to lift loads | Breakage | Replace bearing | High temperature or high frequency | Avoid use at high temperatures or high frequency |

Trolley

| Condition | Reason | Action | Cause | Correction |
|---|--|---|---|--|
| No drive due to wheel skid | Rail tilt | Confirm rail slope is within 1 ° | Improper rail settings | Set up orbit correctly |
| No drive due to wheel skid | Apply oil above orbit wheel tread. | Ensure wheel is clean and unobstructed | Use in environment which outside material does not interfere with parts | Clean orbit regularly |
| Audible friction when travelling on curve track | Friction resistance between wheel and rail | Apply lubricating oil on track tread | | |
| No drive on curve track | Interference of curve track and trolley | Confirm that orbit curve's radius is minimal bending radius | Curve track exceeding limit value | Avoid use on curve track exceeding limit value |
| Wheel raised and unable to be driven | Inclined pull (wheel raised) | | Operation method | Correct use |
| Wheels stopped revolving | Faulty gear connection | Ensure clean space between wheel and gear | Interference from outside material | Check regularly |
| Abnormal sound | Improper adjustment circle | Confirm adjustment circle number and insert position | Insufficient confirmation | Install correctly |
| | Wear of wheel | Confirm wear degrees | Travelling surface has bump | Confirm regularly |
| | Deformation of wheel | Check wheel bending and surface damage | Excessive collision, travelling surface deformed | Replace and use correctly |
| | Aging of wheel bearings | Confirm irregular sound exists when wheel rotates | Reaching service life | Replace |
| | Deformation and wear of track | Confirm rail wear and deformation | Overload or reaching service life | Replace and use correctly |

Electric Trolley



| Condition | Reason | Action | Cause | Correction |
|--------------------------|--------------------------|---|-----------------------|-------------------|
| Wheels stopped revolving | Brake gelling | Open motor cover remove rust and dirt | Usage environment | Inspect regularly |
| | Electric fault | Refer to items of electric chain hoist | | |
| Abnormal sound | Wear of edge guide wheel | Confirm wear degrees | Reaching service life | Confirm regularly |
| | Wear of friction slices | Confirm wear degrees of friction slices | Reaching service life | Confirm regularly |

Manual Trolley



| Condition | Reason | Action | Cause | Correction |
|---------------------------|--|--|-----------------------------|-------------------------------------|
| Unable to move hand chain | Bad connection between hand wheel and hand chain | Properly adjust hand chain on hand wheel | Excessive or improper usage | Replace worn or deformed components |

7. CONVENTIONAL HOIST WIRING DIAGRAM (PWRF - PWRT)



7.1. Hoist Wiring Diagram 1 Speed H3 Fixed PWRF_H3-1SW Series




7.2. Hoist Wiring Diagram 2 Speed H3 Fixed PWRF_H3-2SW Series





7.3. Hoist Wiring Diagram 1 Speed H4 Fixed PWRF_H4-1SW Series





7.4. Hoist Wiring Diagram 2 Speed H4 Fixed PWRF_H4-2SW Series




7.5. Hoist Wiring Diagram 1 Speed H3 Trolley PWRT_H3-1SW Series




7.6. Hoist Wiring Diagram 2 Speed H3 Trolley PWRT_H3-2SW Series



7.7. Hoist Wiring Diagram 1 Speed H4 Trolley PWRT_H4-1SW Series



7.8. Hoist Wiring Diagram 2 Speed H4 Trolley PWRT_H4-2SW Series



1. VFD MANUAL

Chapter 1 Summaries

1.1 Product confirmation

Upon unpacking, please confirm the following: Any damage occurred during transportation; Check whether the model and specifications on the nameplate of inverter are in accordance with your order.

If there is any error, please contact us or distributors.






Fig. 1-1 Model Description rules

The nameplate is on the right bottom of the case of the inverter. The contents are shown



Note: subject to the real equipment.

1.2 Size



(a), Size of inverter below 2.2 Kw

(b), Size of inverter between 3.7 and 7.5 Kw

Table 1-1 Inverters' specification and installation series size (mm)

| Specification | W | W1 | H | H1 | D | D1 | d |
|----------------|-----|-----|-----|-----|-----|-----|---|
| VCD2000-2S0004 | 83 | 66 | 166 | 156 | 118 | / | 5 |
| VCD2000-2S0007 | | | | | | | |
| VCD2000-2S0015 | | | | | | | |
| VCD2000-4T0007 | | | | | | | |
| VCD2000-4T0015 | | | | | | | |
| VCD2000-4T0022 | 106 | 95 | 170 | 157 | 160 | 60 | 5 |
| VCD2000-2S0022 | | | | | | | |
| VCD2000-4T0022 | | | | | | | |
| VCD2000-4T0030 | | | | | | | |
| VCD2000-4T0040 | | | | | | | |
| VCD2000-4T0055 | 152 | 135 | 230 | 215 | 160 | 68 | 6 |
| VCD2000-4T0075 | | | | | | | |
| VCD2000-4T0110 | | | | | | | |
| VCD2000-4T0150 | 200 | 180 | 300 | 280 | 193 | 195 | 6 |

Note: subject to the real equipment

Chapter 2 Installation and Cable Connection

2.1 Major loop Terminal Connection Methods





Fig. 2-1 Easy Major loop Terminal Connection Methods

2.2 Basic Wiring Diagram



2.3 Major loop terminal connection methods

(1) Function of CN 1 terminal as Table 2-1

| Sort | Terminal | Name | Terminal function | Spec |
|--------------------------|----------|---------------------------------------|---|--|
| Output terminal of relay | TA | Multifunctional relay output terminal | Programmable is defined as multifunctional relay output terminal, compare with P4.11 description in Chapter 6 | TA-TC, TA-TB Normally point capability |
| | TB | | | AC250V/2A (COSΦ=1) |
| | TC | | | AC250V/1A (COSΦ=0.4) DC30V/1A |

(2) Control loop terminal CN2, arranged as Fig. 2-2




Fig. 2-2 Control terminal arranging

(3) Function of CN2 terminal as Table 2-2

| Sort | Terminal | Name | Terminal function | Spec |
|---------------------------------|----------|--|---|---|
| Communication | 485+ | RS485 communication port | RS485 differential signal positive terminal RS485 differential signal negative terminal | Twisted-pair/shielding wire in Rs485 port |
| | 485- | | | |
| Multifunctional output terminal | OC | Open circuit collector output terminal 1, 2 | Programmable is defined as multifunctional switch quantity output terminal, compare with P4.10 description in Chapter 6 (Common port: COM) | Light pair isolation output workin voltage range: 9~30V. Max output current: 50mA. usage method compare with P4.10 function description |
| | OC2 | | | |
| Phase output terminal | DO | Open circuit collector pulse output terminal | Programmable is defined as multifunctional pulse output terminal, compare with P4.19, P4.20 description in Chapter 6 (Common port: COM) | Output frequency range depend on P4.20. Max frequency is 20KHz |
| | | | | |
| Analog quantity input | V1 | Analog quantity input V1 | Analog voltage quantity input is accepted (Ground: GND) | Input voltage range : 0~10V (input impedance: 47KΩ) Resolution: 1/1000 |
| | CI | Analog quantity input CI | Analog voltage/current input, Voltage/current are selected by JP3. Default setting is voltage. (Ground: GND) | Input voltage range: 0~10V (input impedance: 47KΩ) Input current range: 0~20mA (input impedance: 500Ω) Resolution: 1/1000 |
| Analog quantity output | AO | Analog quantity output AO1 | Analog voltage/current output, 7 varieties expressed, voltage/current are selected by JP3. Default setting is voltage. (Ground: GND) | Current output range : 4~20mA Voltage output range : 0~10V |
| | | | | |
| Multifunctional output terminal | X1 | Multifunctional Input terminal1 | Programmable is defined as multifunctional switch quantity input terminal, compare with P4 series description in Chapter 6 (Common port: COM) | Light pair isolation input Input impedance: 2KΩ Max input frequency: 200Hz input voltage range: 9~30V |
| | X2 | | | |
| | X3 | | | |
| | X4 | | | |
| | X5 | | | |
| | X6 | | | |
| Power source | 24V | +24V power source | +24V power supply (negative pole: COM) | |
| | 10V | +10V power source | +10V power supply (negative pole: GND) | Max output current: 50mA |
| | GND | +10V common port | Ground of analog signal and +10V power source | COM is isolated from GND inside |
| | COM | +24V common port | Digital signal input/output common port | |

Chapter 3 Function Parameter Table

3.1 Symbol Description

“○”: Means the parameter can be revised during inverter’s running state.

“×”: Means the parameter can not be revised during running state.

“*”: Means read-only parameters can not be revised.

3.2 Function code table

| P0 Series: Basic running parameter | | | | | |
|------------------------------------|---|---|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P0.00 | Control mode selection | 0: V/F Control 1: Vector control 2: Torque control | 1 | 0 | ○ |
| P0.01 | Freq control mode selection | 0: Analog potentiometer on panel 1: ▲, ▼ on key board 2: No.Setting1,operation panel 3: No.Setting2,up/down on terminal 4: No.setting3,serial port 5: VI (VI-GND) 6: CI (CI-GND) 7: Terminal fuse 8: Combination (see P3.00) 9: VI*CI 10: VI*control panel▲, ▼ 11: VI*potentiometer on control panel 12: Factory reserved | 1 | 0 | ○ |
| P0.02 | Running freq.Digital setting | P0.19low freq.limit-P0.20high freq.limit | 0.01Hz | 50.00Hz | ○ |
| P0.03 | Running command mode selection | 0: Panel running freq.Mode 1: Terminal running command mode 2: Uart port running order 485 | 1 | 0 | ○ |
| P0.04 | Running direction setting | Units: 0: Forward 1: REV Decade: 0: allow REV1; prohibit REV | 1 | 10 | ○ |
| P0.05 | FWD/REV dead time | 0.0~120.0s | 0.1s | 0.1s | ○ |
| P0.06 | Highest output freq. | 50.00Hz~500.00Hz | 0.01Hz | 50.00Hz | × |
| P0.07 | Basic running freq. | 1.00Hz~500.00Hz | 0.01Hz | 50.00Hz | × |
| P0.08 | Highest output voltage | 1~480V | 1V | Rated voltage | × |
| P0.09 | Torque boost | 0.0%~30.0% | 0.1% | 2.0% | × |
| P0.10 | Cut-off freq of torque boost | 0.00Hz~Basic running freq.P0.07 | 0.00 | 25.00Hz | ○ |
| P0.11 | Torque boost mode | 0: Manual 1: Auto | 1 | 0 | ○ |
| P0.12 | Carrier freq. | 1.0K~15.0K | 0.1K | 8.0K | × |
| P0.13 | Acc/Dec mode selection | 0: Linear Acc/Dec 1: Curve Acc/Dec | 1 | 0 | × |
| P0.14 | Time of S curve's initial part | 10.0%~50.0% (Acc/Dec time) P0.14+P0.15 ≤ 90% | 0.1% | 20.0% | ○ |
| P0.15 | Time of S curve's rising part | 10.0%~80.0% (Acc/Dec time) P0.14+P0.15 ≤ 90% | 0.1% | 60.0% | ○ |
| P0.16 | Acc/Dec time unit | 0: Second 1: Minute | 0 | 0 | × |
| P0.17 | Acc time 1 | 0.01~6000.0 | 0.01 | 20.00 | ○ |
| P0.18 | Dec time 1 | 0.01~6000.0 | 0.01 | 20.00 | ○ |
| P0.19 | High freq.limit | Low freq.limit-highest output freq.P0.06 | 0.01Hz | 50.00Hz | × |
| P0.20 | Low freq.limit | 0.00Hz~Upper limit freq. | 0.01Hz | 0.00Hz | × |
| P0.21 | Lower limit freq. running mode | 0: Running at lower limit freq. 1: Stop | 1 | 0 | × |
| P0.22 | V/F curve setting | 0: Constant torque curve 1: Reduced torque curve 1 (1.2 times the power) 2: Reduced torque curve 2 (1.7 times the power) 3: Reduced torque curve 3 (2.0 times the power) 4: Customized V/F curve | 1 | 0 | × |
| P0.23 | V/F Freq.value P3 | P0.25 ~ P0.07 Basic running freq. | 0.01Hz | 0.00Hz | × |
| P0.24 | V/F Volt.value V3 | P0.26 ~ 100.0% | 0.1% | 0.0% | × |
| P0.25 | V/F Freq.value P2 | P0.27 ~ P0.23 | 0.01Hz | 0.00Hz | × |
| P0.26 | V/F Volt.value V2 | P0.28 ~ P0.24 | 0.1% | 0.0% | × |
| P0.27 | V/F Freq.value P1 | 0.00~P0.25 | 0.01Hz | 0.00Hz | × |
| P0.28 | V/F Volt.value V1 | 0~ P0.26 | 0.1% | 0.0% | × |
| P0.29 | Up/down controlled freq. save mode in power off | 0: Don't save power lost.When start again, use P0.02 freq. to be the starting value. 1: Save UP/DOWN controlling freq. | 1 | 1 | ○ |

| P1 Series: Frequency setting parameter | | | | | |
|--|-------------------------------------|------------------------|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P1.00 | Analog filtering time constant | 0.01~30.00s | 0.01s | 0.20s | ○ |
| P1.01 | VI channel gains | 0.01~9.99 | 0.01 | 1.00 | ○ |
| P1.02 | VI min given | 0.00~P1.04 | 0.01Hz | 0.00V | ○ |
| P1.03 | Corresponding freq.to VI min given | 0.00~Upper limit freq. | 0.01Hz | 0.00Hz | ○ |
| P1.04 | VI max given | P1.04~10.00V | 0.01V | 10.00V | ○ |
| P1.05 | Corresponding freq.to VI max given. | 0.00~Upper limit freq. | 0.01Hz | 50.00Hz | ○ |
| P1.06 | CI channel gains | 0.01~ 9.99 | 0.01 | 1.00 | ○ |
| P1.07 | CI min given | 0.00~ P1.09 | 0.01V | 0.00V | ○ |
| P1.08 | Corresponding freq.to CI min given | 0.00~Upper limit freq. | 0.01Hz | 0.00Hz | ○ |
| P1.09 | CI max given | P1.07 ~10.00V | 0.01V | 10.00V | ○ |
| P1.10 | Corresponding freq.to CI max given | 0.00~Upper limit freq. | 0.01Hz | 50.00Hz | ○ |

| | | | | | |
|-------|---------------------------------------|---|--------|---------|---|
| P1.11 | Max input pulse freq. | 0.1~20.0K | 0.1K | 10.0K | ○ |
| P1.12 | Pulse min given | 0.0~P2.14 (Pulse max given) | 0.1K | 0.0K | ○ |
| P1.13 | Corresponding freq.to pulse min given | 0.00~Upper limit freq. | 0.01Hz | 0.00Hz | ○ |
| P1.14 | Pulse max given | P1.12 (Pulse min given) ~ P1.11 (Max input pulse freq.) | 0.1K | 10.0K | ○ |
| P1.15 | Corresponding freq.to pulse max given | 0.00~Upper limit freq. | 0.01Hz | 50.00Hz | ○ |
| P1.16 | The analog input accuracy | 0.0~100% | 0.1% | 0.2% | ○ |

| P2 Series: Start/Break parameter | | | | | |
|----------------------------------|--------------------------------|---|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P2.00 | Start mode | 0: Start from start freq. 1: Brake at first, then start from start freq. 2: Track speed, then start | 1 | 0 | × |
| P2.01 | Start freq. | 0.40~20.00Hz | 0.01Hz | 0.50Hz | ○ |
| P2.02 | Start freq.running duration | 0.0~30.0s | 0.1s | 0.0s | ○ |
| P2.03 | DC brake current at start | 0.0~80.0% | 0.1% | 0% | ○ |
| P2.04 | DC brake time at start | 0.0~60.0s | 0.1s | 0.0s | ○ |
| P2.05 | Stop mode | 0: Dec to stop 1: Free stop 2: Dec+DC brake | 1 | 0 | × |
| P2.06 | Start freq.of DC brake at stop | 0.0~15.00Hz | 0.0Hz | 3.00Hz | ○ |
| P2.07 | DC brake time at stop | 0.0~60.0s | 0.1s | 0.0s | ○ |
| P2.08 | DC brake current at stop | 0.0~80.0% | 0.1% | 0.0% | ○ |

| P3 Series: Auxiliary running parameter | | | | | |
|--|----------------------------------|---|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P3.00 | Freq control mode combination | 0: VI+CI 1: VI-CI 2: External pulse given+ VI+ control panel ▲, ▼keys given 3: External pulse given-VI- control panel ▲, ▼keys given 4: External pulse given+CI 5: External pulse given-CI 6: RS485 Given+VI+Control panel▲, ▼keys given 7: RS485 Given-VI-Control panel▲, ▼keys given 8: RS485 Given+CI+Control panel▲, ▼keys given 9: RS485 Given-CI-Control panel▲, ▼keys given 10: RS485 Given+CI+external pulse given 11: RS485 Given+VI+external pulse given 12: RS485 Given+VI+external pulse given 13: RS485 Given-VI+external pulse given 14: VI+CI+Control panel▲, ▼keys given +digital given (P0.02) 15: VI+CI-Control panel▲, ▼keys given +digital given (P0.02) 16: MAX (VI, CI) 17: MIN (VI, CI) 18: MAX (VI, CI, PULSE) 19: MIN (VI, CI, PULSE) 20: VI, CI (Valid except 0,VI prior) | 1 | 0 | × |
| P3.01 | Parameter Initialization setting | LED units: 0: All parameters are allowed to be revised 1: All parameters are not allowed to be revised except this parameter itself 2: All parameters are not allowed to be revised except P0.02 parameter and this parameter itself. LED tons: 0: Inaction 1: Factory default reset 2: Clear history fault record | 1 | 0 | × |

| P3 Series: Auxiliary running parameter | | | | | |
|--|-----------------------------|---|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P3.02 | Parameter copy | 0:Inaction 1:Parameter upload 2:Parameter download Note: only valid in remote control mode | 1 | 0 | × |
| P3.03 | Auto energy saving running | 0: Inaction 1: Action | 1 | 0 | × |
| P3.04 | AVR function | 0: Inaction 1: Always active 2: Inaction only during Dec | 1 | 0 | × |
| P3.05 | Slip freq. compensation | 0~150% | 1% | 0% | × |
| P3.06 | JOG freq. | 0.10~50.00Hz | 0.01Hz | 5.00Hz | ○ |
| P3.07 | JOG Acc time | 0.1~60.0s | 0.1s | 20.0s | ○ |
| P3.08 | JOG Dec time | 0.1~60.0s | 0.1s | 20.0s | ○ |
| P3.09 | Communication configuration | LED units:baud rate 0: 1200BPS 1: 2400BPS 2: 4800BPS 3: 9600BPS 4: 19200BPS 5: 38400BPS LED tons:data format 0: 1-7-2 Format, no parity | 1 | 154 | × |

| | | | | | |
|-------|---------------------------------------|--|--------|---------|---|
| | | 1: 1-7-1 Format, odd parity 2: 1-7-1 Format, even parity 3: 1-8-2 Format, no parity 4: 1-8-1 Format, odd parity 5: 1-8-1 Format, even parity 6: 1-8-1 Format, no parity LED hundreds: communication mode 0: MODBUS, ASCII Mode 1: MODBUS, RTU Mode | | | |
| P3.10 | Local address | 0: Broadcast address 248: Host address | 1 | 1 | × |
| P3.11 | Communication overtime detection time | 0.0~1000.0s 0.0: Function invalid | 0.1s | 0.0s | × |
| P3.12 | Local response delay | 0~1000ms | 1 | 5ms | × |
| P3.13 | Communication freq setting proportion | 0.01~1.00 | 0.01 | 1.00 | × |
| P3.14 | Acc time2 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.15 | Dec time2 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.16 | Acc time 3 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.17 | Dec time 3 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.18 | Acc time 4 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.19 | Dec time 4 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.20 | Acc time 5 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.21 | Dec time 5 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.22 | Acc time 6 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.23 | Dec time 6 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.24 | Acc time 7 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.25 | Dec time 7 | 0.1~6000.0 | 0.1 | 20.0 | ○ |
| P3.26 | Multi-stage freq.1 | Lower limit freq.~Upper limit freq. | 0.01Hz | 5.00Hz | ○ |
| P3.27 | Multi-stage freq.2 | Lower limit freq.~Upper limit freq. | 0.01Hz | 10.00Hz | ○ |
| P3.28 | Multi-stage freq.3 | Lower limit freq.~Upper limit freq. | 0.01Hz | 20.00Hz | ○ |
| P3.29 | Multi-stage freq.4 | Lower limit freq.~Upper limit freq. | 0.01Hz | 30.00Hz | ○ |
| P3.30 | Multi-stage freq.5 | Lower limit freq.~Upper limit freq. | 0.01Hz | 40.00Hz | ○ |
| P3.31 | Multi-stage freq.6 | Lower limit freq.~Upper limit freq. | 0.01Hz | 45.00Hz | ○ |
| P3.32 | Multi-stage freq.7 | Lower limit freq.~Upper limit freq. | 0.01Hz | 50.00Hz | ○ |
| P3.33 | Jump freq.1 | 0.00~500.00Hz | 0.01Hz | 0.00Hz | × |
| P3.34 | Jump freq.range 1 | 0.00~30.00Hz | 0.01Hz | 0.00Hz | × |
| P3.35 | Jump freq.2 | 0.00~500.00Hz | 0.01Hz | 0.00Hz | × |
| P3.36 | Jump freq.range 2 | 0.00~30.00Hz | 0.01Hz | 0.00Hz | × |
| P3.37 | Jump freq.3 | 0.00~500.00Hz | 0.01Hz | 0.00Hz | × |
| P3.38 | Jump freq.range 3 | 0.00~30.00Hz | 0.01Hz | 0.00Hz | × |
| P3.39 | Setting running time | 0~65.535K (Hour) | 0.001K | 0.000K | ○ |
| P3.40 | Total running time | 0~65.535K (Hour) | 0.001K | 0.000K | * |
| P3.41 | Parameter display selection 1 | 0000~1111 Units: running time 0: Not displayed 1: Displayed Tens:input/output terminal state 0: Not displayed 1: Displayed Hundreds:analog input VI 0: Not displayed 1: Displayed Thousands:analog input CI 0: Not displayed 1: Displayed | 1 | 0000 | ○ |
| P3.42 | Parameter display selection 2 | 0000~1111 Units: External pulse input value 0: Not displayed 1: Displayed Tens:Inverter rated current 0: Not displayed 1: Displayed Hundreds: Inverter rated voltage 0: Not displayed 1: Displayed | 1 | 0000 | ○ |
| P3.43 | Parameter display selection 3 | 00~15 0: The output frequency 1: According to a set frequency 2: According to the output voltage 3: According to the output current 4: According to the dc bus voltage 5: Temperature display module 6: According to motor speed 7: Shows that the frequency converter has run time 8: According to the input terminals 9: According to V1 value 10: According to C1value 11: According to PLUSE value 12: According to inverter rated current 13:According to inverter rated voltage 14: Show no unit of speed, Pole at the end of the shaft speed 15: According to frequency converter model | 1 | 00 | ○ |
| P3.44 | Without unit display coefficient | 0.1~60.0 | 0.1 | 1.0 | ○ |
| P3.45 | JOG/REV function selection | 0: Select JOG running 1: Select reverse running | 1 | 0 | × |

| P4 Series: Terminal function parameter | | | | | |
|--|---|--|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P4.00 | Input terminal X1 function selection | 0: Terminal idle | 1 | 38 | × |
| | | 1: Multi-stage speed control terminal 1 | | | |
| | | 2: Multi-stage speed control terminal 2 | | | |
| | | 3: Multi-stage speed control terminal 3 | | | |
| | | 4: External FWD/JOG control input | | | |
| | | 5: External REV/JOG control input | | | |
| | | 6: Acc/Dec time selection terminal 1 | | | |
| | | 7: Acc/Dec time selection terminal 2 | | | |
| | | 8: Acc/Dec time selection terminal 3 | | | |
| | | 9: 3-wire control mode | | | |
| | | 10: Free stop input (FRS) | | | |
| | | 11: External stop command | | | |
| | | 12: DC braking stop input command (DB) | | | |
| | | 13: Inverter running prohibited | | | |
| | | 14: Freq. increase command (IUP) | | | |
| | | 15: Freq. decrease command (DOWN) | | | |
| | | 16: Acc/Dec prohibited command | | | |
| | | 17: External reset input | | | |
| | | 18: External fault input (normally opens) | | | |
| | | 19: Freq. control mode selection 1 | | | |
| | | 20: Freq. control mode selection 2 | | | |
| | | 21: Freq. control mode selection 3 | | | |
| | | 22: Switch to terminal control mode | | | |
| | | 23 : Running command control mode selection 1 | | | |
| | | 24 : Running command control mode selection 2 | | | |
| | | 25: Wobulation running start | | | |
| | | 26: Wobulation running reset | | | |
| | | 27: Close loop disabled | | | |
| | | 28: Simple PLC running pause command | | | |
| | | 29: PLC disabled | | | |
| | | 30: PLC reset in stop state | | | |
| | | 31: Switch to C1 freq.given | | | |
| | | 32: Counter trig signal input | | | |
| | | 33: Counter clear input | | | |
| | | 34: External interrupt input | | | |
| | | 35: Pulse freq input (only valid to X6) | | | |
| | | 36: Actual length clear input | | | |
| | | 37 : Three line running control downtime, Normal Open | | | |
| | | 38: FWD | | | |
| | | 39: REV | | | |
| 40: Reserve | | | | | |
| P4.01 | Input terminal X2 function selection | Ditto | 1 | 39 | × |
| P4.02 | Input terminal X3 function selection | Ditto | 1 | 4 | × |
| P4.03 | Input terminal X4 function selection | Ditto | 1 | 1 | × |
| P4.04 | Input terminal X5 function selection | Ditto | 1 | 2 | × |
| P4.05 | Input terminal X6 function selection | Ditto | 1 | 3 | × |
| P4.06 | Input terminal FWD | Ditto | 1 | 0 | |
| P4.07 | Input terminal REV | Ditto | 1 | 0 | |
| P4.08 | FWD/REV running mode selection | 0: 2-wire control mode 1 1: 2-wire control mode 2 2: 3-wire control mode 1 3: 3-wire control mode 2 | 1 | 0 | × |
| P4.09 | UP/DN speed rate | 0.01~99.99Hz/s | 0.01 | 1.00Hz | ○ |
| P4.10 | 2-way open collector output terminal OC | 0: Inverter running signal(RUN) | 1 | 0 | × |
| | | 1: Freq.arrive signal(FAR) | | | |
| | | 2: Freq.detected signal level(FDT1) | | | |
| | | 3: Freq.detected signal level(FDT2) | | | |
| | | 4: Over load pre-alarm signal(OL) | | | |
| | | 5: Undervoltage lock(LLU) | | | |
| | | 6: External fault stop (EXT) | | | |
| | | 7: Output freq.upper limit arrive (FH) | | | |
| | | 8: Output freq.lower limit arrive (FL) | | | |
| | | 9: Inverter zero speed running | | | |
| | | 10: Simple PLC stage running finish | | | |
| | | 11: One PLC running cycle finish | | | |
| | | 12: Setting count value arrive | | | |
| | | 13: Specified count value arrive | | | |
| | | 14: Inverter ready for running(RDY) | | | |
| | | 15: Inverter fault | | | |
| | | 16: Start freq.running time | | | |
| | | 17: DC brake time at start | | | |
| | | 18: DC brake time at stop | | | |
| | | 19: Wobulation upper/lower freq. limit | | | |
| | | 20: Setting running time arrive | | | |
| | | 21: Constant pressure water supply pump output control | | | |

| | | | | | |
|-------|--|---|--------|---------|---|
| P4.11 | Relay output selection | Ditto | 1 | 15 | × |
| P4.12 | Freq arrive detected range (FAR) | 0.00~50.00Hz | 0.01Hz | 5.00Hz | ○ |
| P4.13 | FDT1 level | 0.00~Upper limit freq. | 0.01Hz | 10.00Hz | ○ |
| P4.14 | FDT1 lag | 0.00~50.00Hz | 0.01Hz | 1.00Hz | ○ |
| P4.15 | FDT2 level | 0.00~Upper limit freq. | 0.01Hz | 10.00Hz | ○ |
| P4.16 | FDT2 lag | 0.00~50.00Hz | 0.01Hz | 1.00Hz | ○ |
| P4.17 | Analog output (AO) selection | 0: Output freq.(0-upper limit freq.) 1: Output current(0~2 times motor rated current) 2: Output voltage(0~1.2 times inverter rated voltage) 3: Busbar voltage (0~800V) 4: PID given 5: PID feedback 6: VI (0~10V) 7: CI(0~10V/4~20mA) | 1 | 0 | ○ |
| P4.18 | Analog output (AO) gain | 0.10~2.00 | 0.01 | 1.00 | ○ |
| P4.19 | DO output terminal function selection | 0: Output freq.(0-upper limit freq.) 1: Output current(0~2 times motor rated current) 2: Output voltage(0~1.2 times inverter rated voltage) 3: Busbar voltage (0~800V) 4: PID given 5: PID feedback 6: VI (0~10V) 7: CI(0~10V/4~20mA) 8: Constant pressure water supply pump output control | 1 | 0 | ○ |
| P4.20 | DO max pulse output freq. | 0.1K~20.0K (Max 20KHz) | 0.1KHz | 10.0KHz | ○ |
| P4.21 | Setting count value given | F4.22~9999 | 1 | 0 | ○ |
| P4.22 | Specified count value given | 0~F4.21 | 1 | 0 | ○ |
| P4.23 | Over load pre-alarm detected level | 20%~200% | 1 | 130% | ○ |
| P4.24 | Over load pre-alarm delay time | 0.0~20.0s | 0.1s | 5.0s | ○ |
| P4.25 | 2-way open collector output terminal OC2 | Same as P4.10 | 1 | 0 | × |
| P4.26 | Terminal signal filtering | 0~4 | 1 | 4 | × |

| P5 Series: Protection function parameter | | | | | |
|--|---|---|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P5.00 | Motor over load protection mode selection | 0: Stop output 1: Inaction | 1 | 0 | × |
| P5.01 | Motor over load protection coefficient | 20~120% | 1 | 100% | × |
| P5.02 | Over voltage stall protection | 0: Prohibited 1: Allowed | 1 | 1 | × |
| P5.03 | Over voltage stall point | 380V: 120~150% 220V: 110~130% | 1% | 140% 120% | ○ |
| P5.04 | Auto current limit level | 10%~200% | 1% | 150% | ○ |
| P5.05 | Freq.drop rate during current limit | 0.00~99.99Hz/s | 0.01Hz/s | 15.00Hz/s | ○ |
| P5.06 | Auto current limit selection | 0: Invalid during constant speed run 1: Valid during constant speed run Note: Always valid during Acc/Dec | 1 | 1 | × |
| P5.07 | Restart setting after power failure | 0: Inaction 1: Action | 1 | 0 | × |
| P5.08 | Restart waiting time after power failure | 0.0~10.0s | 0.1s | 0.5s | × |
| P5.09 | Fault self-recovery times | 0~10 0: Self-recovery invalid Note: Self-recovery invalid while over load or over heat | 1 | 0 | × |
| P5.10 | Self-recovery interval time | 0.5~20.0s | 0.1s | 5.0s | × |
| P5.11 | Output missing phase protection | 0: Inaction 1: Action | 1 | 1 | × |
| P5.12 | Input missing phase protection | 0: Inaction 1: Action | 1 | 0 | ○ |
| P5.13 | Overheating protection module | 0~200 | 1 | 80 | ○ |

| P6 Series: Fault record parameter | | | | | |
|-----------------------------------|----------------------------------|----------------------------------|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P6.00 | Last fault record | Last fault record | 1 | 0 | * |
| P6.01 | Output freq. in last fault | Output freq.in last fault | 0.01Hz | 0 | * |
| P6.02 | Setting freq. in last fault | Setting freq.in last fault | 0.01Hz | 0 | * |
| P6.03 | Output current in last fault | Output current in last fault | 0.1A | 0 | * |
| P6.04 | Output voltage in last fault | Output voltage in last fault | 1V | 0 | * |
| P6.05 | DC busbar voltage in last fault | DC busbar voltage in last fault | 1V | 0 | * |
| P6.06 | Module temperature in last fault | Module temperature in last fault | 1°C | 0 | * |
| P6.07 | Last 2 fault record | Last 2 fault record | 1 | 0 | * |
| P6.08 | Last 3 fault record | Last 3 fault record | 1 | 0 | * |

| | | | | | |
|-------|---------------------|---------------------|---|---|---|
| P6.09 | Last 4 fault record | Last 4 fault record | 1 | 0 | * |
| P6.10 | Last 5 fault record | Last 5 fault record | 1 | 0 | * |
| P6.11 | Last 6 fault record | Last 6 fault record | 1 | 0 | * |

| P7 Series: Close loop control parameter(PID) | | | | | |
|--|---|--|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P7.00 | Close loop running control selection | 0: Invalid PID 1: Valid PID | 1 | 0 | × |
| P7.01 | Close loop given channel selection | 0: Digital given 1: VI analog 0~10V voltage given 2: CI analog given 3: Control panel potentiometer given 4: RS485 Communications given 5: PLUSE given, only X6 effectivity | 1 | 0 | ○ |
| P7.02 | Feedback channel selection | 0: VI analog 0~10V input voltage 1: CI analog input 2: VI+CI 3: VI-CI 4: Min (VI, CI) 5: Max (VI, CI) 6: Pulse feedback | 1 | 0 | ○ |
| P7.03 | Given channel filtering time constant | 0: No feedforward function 1: P7.05 Digital setting feedforward 2: VI analog 0~10V voltage feedforward 3: CI analog feedforward 4: Control panel potentiometer feedforward 5: RS485 Communications feedforward 6: PLUSE feedforward, only X6 effectivity | 1 | 0 | ○ |
| P7.04 | Feedback channel filtering time constant | 0.01~50.00s | 0.01s | 0.50s | ○ |
| P7.05 | Given value digital setting | 0.000~20.00Mpa refer to P7.27 | 0.001Mpa | 0.000Mpa | ○ |
| P7.06 | Close loop regulation characteristic | 0: Positive effect 1: Negative effect | 1 | 0 | ○ |
| P7.07 | Feedback channel gain | 0.01~10.00 | 0.01 | 0 | ○ |
| P7.08 | Lower limit pressure value | 0.001~P7.09 | 0.001 | 0.001 | ○ |
| P7.09 | Upper limit pressure value | P7.08~P7.27 | 0.001Mpa | 1.000Mpa | ○ |
| P7.10 | Proportional gain(KP1) | 0~6000.0 | 0.1 | 20.0 | ○ |
| P7.11 | Proportional gain(KP2) | 0~6000.0 | 0.1 | 200.0 | ○ |
| P7.12 | Proportional gain(KP3) | 0~6000.0 | 0.1 | 1000.0 | ○ |
| P7.13 | Proportional gain(KP4) | 0~6000.0 | 0.1 | 5000.0 | ○ |
| P7.14 | Sampling period | 0.01~1.00s | 0.01s | 0.10s | ○ |
| P7.15 | Allowed deviation limit | 0~20% | 1% | 0% | ○ |
| P7.16 | PID feedback disconnection detection threshold | 0.0^20.0% | 0.1% | 0.0% | ○ |
| P7.17 | PID feedback disconnection action selection | 0: Stop. 1: Running at freq.defined by P0.02 2: Running at upper limit freq. 3: Running at half of upper limit freq. | 1 | 0 | ○ |
| P7.18 | PID feedback disconnection action delay time | 0.01~5.00s | 0.01s | 1.00s | ○ |
| P7.19 | Revival pressure threshold | 0.001~P7.27 | 0.001Mpa | 0.001Mpa | ○ |
| P7.20 | Sleeping pressure threshold | P7.19~P7.27 | 0.001Mpa | 1.000Mpa | ○ |
| P7.21 | Sleeping threshold continuous time | 0~250s | 1 | 10s | ○ |
| P7.22 | Sleeping freq. | 0.00~500.00Hz | 0.01 | 20.00Hz | ○ |
| P7.23 | Sleeping freq.continuous time | 0~250s | 1 | 10s | ○ |
| P7.24 | Alarm lower limit pressure | 0.001~P7.25 | 0.001Mpa | 0.001Mpa | ○ |
| P7.25 | Alarm upper limit pressure | P7.24~P7.27 | 0.001Mpa | 1.000Mpa | ○ |
| P7.26 | Constant pressure water supply mode invalid | 0: Constant pressure water supply mode invalid 1: 1-drive-1 water supply mode 2: 1-drive-2 water supply mode | 1 | 0 | ○ |
| P7.27 | Pressure meter measuring range | 0.001~20.00Mpa | 0.001Mpa | 1.000Mpa | ○ |
| P7.28 | Multi pumps running mode | 0: Fixed order switch 1: Timing rotation | 1 | 0 | ○ |
| P7.29 | Timing rotation interval time | 0.5~100.0 Hour | 0.1 Hour | 5.0 Hour | ○ |
| P7.30 | Pump switch judge time | 0.1 ~ 1000.0s | 0.1s | 300.0s | ○ |
| P7.31 | Solenoid switch delay time | 0.1~10.0s | 0.1s | 0.5s | ○ |
| P7.32 | Water supply monitoring parameter display selection | 0: B-09, B-10 display VI, CI voltage value 1: B-09, B-10 display PID given pressure and feedback pressure | 1 | 0 | ○ |
| P7.33 | given channel filtering | 0.01~50.00s | 0.01s | 0.50s | ○ |

| P8 Series: PLC running parameter | | | | | |
|----------------------------------|------------------------------|--|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P8.00 | Simple PLC running selection | 0000~1113 LED units: mode selection 0: Inaction 1: Stop after single cycle 2: Running at final freq. after single cycle 3: Continuous cycle LED tens: PLC restart selection 0: Restart from the first stage 1: Restart from the freq. of break stage LED hundreds:PLC state parameter store mode selection 0: Without store 1: Store LED thousands:PLC running time unit 0: Second 1: Minute | 1 | 0000 | × |
| | | 000~621 LED units: freq.setting 0: Multi-stage freq.i (i=1~7) 1: Freq.given defined by P0.01 LED tens: direction selection 0: Forward 1: Reverse 2: Controlled by running command LED hundreds:Acc/Dec time selection 0: Acc/Dec time 1 1: Acc/Dec time 2 2: Acc/Dec time 3 3: Acc/Dec time 4 4: Acc/Dec time 5 5: Acc/Dec time 6 6: Acc/Dec time 7 | 1 | 000 | ○ |
| P8.02 | Stage 1 running time | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.03 | Stage 2 setting | 000~621 | 1 | 000 | ○ |
| P8.04 | Stage 2 running time | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.05 | Stage 3 setting | 000~621 | 1 | 000 | ○ |
| P8.06 | Stage 3 running time | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.07 | Stage 4 setting | 000~621 | 1 | 000 | ○ |
| P8.08 | Stage 4 running time | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.09 | Stage 5 setting | 000~621 | 1 | 000 | ○ |
| P8.10 | Stage 5 running time | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.11 | Stage 6 setting | 000~621 | 1 | 000 | ○ |
| P8.12 | Stage 6 running time | 0.1~6000.0 | 0.1 | 10.0 | ○ |
| P8.13 | Stage 7 setting | 000~621 | 1 | 000 | ○ |
| P8.14 | Stage 7 running time | 0.1~6000.0 | 0.1 | 10.0 | ○ |

| P9 Series: Hunting freq.AND measure function parameter | | | | | |
|--|--------------------------------|--|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| P9.00 | Wobulation function selection | 0: Inaction 1: Action | 1 | 0 | × |
| P9.01 | Wobulation running mode | 0000~11 LED units: start mode 0: Auto start 1: Manual start by terminal LED tens:Wobulation amplitude control 0: Variable amplitude 1: Fixed amplitude | 1 | 00 | × |
| | | 0.00~500.00Hz | 0.01Hz | 0.00Hz | ○ |
| P9.03 | Preset wobulation waiting time | 0.0~3600.0s | 0.1s | 0.0s | ○ |
| P9.04 | Wobulation amplitude | 0.0~50.0% | 0.1% | 0.0% | ○ |
| P9.05 | Kick freq. | 0.0~50.0% (relative to P9.04) | 0.1% | 0.0% | ○ |
| P9.06 | Wobulation cycle | 0.1~999.9s | 0.1s | 10.0s | ○ |
| P9.07 | Delta wave ascent time | 0.0 ~ 98.0 % (The pendulum frequency cycle) | 0.1% | 50.0% | ○ |
| P9.08 | Setting length | 0.000 ~ 65.535(km) | 0.001km | 0.000km | ○ |
| P9.09 | Actual length | 0.0~65.535km(Auto store when power failure) | 0.001km | 0.000km | ○ |
| P9.10 | Length magnification | 0.001~30.000 | 0.001 | 1.000 | ○ |
| P9.11 | Length correction coefficient | 0.001~1.000 | 0.001 | 1.000 | ○ |
| P9.12 | Measurement axis circumference | 0.01~100.00cm | 0.01cm | 10.00cm | ○ |
| P9.13 | Axis pulse | 1~9999 | 1 | 1 | ○ |
| P9.14 | User password | 1~9999 | 1 | 0 | ○ |

| PA Series: Vector control parameter | | | | | |
|-------------------------------------|---|---|-----------|-----------------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| PA.00 | Motor parameter self-learning function | 0: Inaction 1: Self-learning at rest 2: Banned from learning. Don't need to lift the load | 1 | 0 | × |
| PA.01 | Motor rated power | 0.0~900.0KW | 0.1 | Depends on model type | |
| PA.02 | Motor rated voltage | 0~400V | 1 | Depends on model type | × |
| PA.03 | Motor rated current | 0.01~500.00A | 0.01A | Depends on model type | × |
| PA.04 | Motor rated frequency | 1~500Hz | 1Hz | Depends on model type | × |
| PA.05 | Motor rated rotating speed | 1~9999 r/min | 1r/min | Depends on model type | × |
| PA.06 | Motor poles number | 2~16 | 1 | Depends on model type | × |
| PA.07 | Motor stator resistance | 0.001~50.000Ω | 0.001Ω | Depends on model type | × |
| PA.08 | Motor stator resistance | 0.001~50.000Ω | 0.001Ω | Depends on model type | × |
| PA.09 | Motor stator inductance | 0.1~5000.0 mH | 0.1mH | Depends on model type | × |
| PA.10 | Motor rotor inductance | 0.1~5000.0 mH | 0.1mH | Depends on model type | × |
| PA.11 | Motor stator and rotor mutual inductance | 0.01~655.32 A | 0.01A | Depends on model type | ○ |
| PA.12 | Torque current over-current protection factor | 0~200.0% | 0.1% | 150.0% | ○ |
| PA.13 | Speed deviation ratio adjustment coefficient | 0~9999 | 1 | 15 | ○ |
| PA.14 | Speed deviation integral adjustment coefficient | 0~100.00 | 0.01 | 2.00 | ○ |
| PA.15 | Vector torque | 0~200.0% | 0.1% | 50.0% | × |
| PA.16 | Low switching frequency | 0~400.00Hz | 0.01Hz | 5.00Hz | ○ |
| PA.17 | Speed loop gain 2 proportion | 0~9999 | 1 | 10 | ○ |
| PA.18 | 2 speed loop integral time | 0.01~100.00 | 0.01 | 3.00 | ○ |
| PA.19 | High frequency switching | 0.01~400.00Hz | 0.01Hz | 15.00Hz | ○ |
| PA.20 | VC slip compensation coefficient | 50~200 | 1 | 100 | ○ |
| PA.21 | Switching voltage closed-loop flux calculation | 0~30 | 1 | 15 | × |
| PA.22 | Open loop switching frequency | 0~10.00Hz | 0.01Hz | 0.00Hz | × |
| PA.23 | Speed filter coefficients | 0~1.000 | 0.001 | 0.625 | × |
| PA.24 | No-load current compensation coefficient | 0~9.999 | 0.001 | 1.000 | × |
| PA.25 | Compensation coefficient of resistance | 0~9.999 | 0.001 | 1.000 | × |

| Pb Series: Inhibition of oscillation parameters and torque control | | | | | |
|--|---|---|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| Pb.00 | Inhibiting oscillation frequency threshold point | 0~100% | 1% | 5% | ○ |
| Pb.01 | Inhibition of concussion high frequency threshold point | 0~100% | 1% | 5% | ○ |
| Pb.02 | Restrain oscillation amplitude limit value | 0~100% | 1% | 10% | ○ |
| Pb.03 | Inhibition of high cut-off frequency oscillation | 0~400.00Hz | 0.01Hz | 12.50Hz | ○ |
| Pb.04 | Inhibition of shock | 0: Open the inhibition of shock 1: Closed inhibit shock | 1 | 0 | ○ |
| Pb.05 | The torque setting | 0: Pb.06 digital giving 1: V1 mode 0~10V VOLT REF 2: CI analog input 3: Panel potentiometer given 4: RS485 Communications given 5: PLUSE given, only X6 | 1 | 0 | ○ |
| Pb.06 | The keyboard is set torque | -200.0%~200.0% | 0.1% | 50% | ○ |
| Pb.07 | PWM Mode | Unit: 0: 7 sections of cut 5 stages 1: The entire 7 paragraph 2: The entire 5 paragraph 3: Reserve 4: EPS transformer loading Decade: 0: Close the overmodulation 1: Open the part over modulation 2: Open all the over modulation Hundreds: 0: Reserve 1: Reserve | 000~114 | 000 | × |

| PF Series: Factory parameter | | | | | |
|------------------------------|----------|-------------------|-----------|-----------------|--------|
| Func.Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| PC.00~PC.18 | Reserved | — | — | — | — |


| Pd Series: Customized machine parameters | | | | | |
|--|----------|-------------------|-----------|-----------------|--------|
| Func.Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| Pd.00~Pd.16 | Reserved | — | — | — | — |

5.3 The state parameter monitor table

| B-Monitoring function parameters | | | | | |
|----------------------------------|-----------------------------|---|-----------|-----------------|--------|
| Func. Code | Name | Range of settings | Min. Unit | Factory setting | Change |
| b-00 | Output fre | Current output freq. | 0.01Hz | | * |
| b-01 | Setting freq. | Current setting freq. | 0.01Hz | | * |
| b-02 | Output voltage | Effective value of current output voltage | 1V | | * |
| b-03 | Output current | Effective value of current output current | 0.1A | | * |
| b-04 | Busbar voltage | Current DC busbar voltage | 1V | | * |
| b-05 | Module temperature | IGBT heat sink temperature | 1°C | | * |
| b-06 | Motor speed | Current motor speed | 1r/min | | * |
| b-07 | Running time | Continuous running time at a time | 1 H | | * |
| b-08 | Input/output terminal state | Input/output terminal state | — | | * |
| b-09 | Analog input V1 | Analog input V1 value | 0.01V | | * |
| b-10 | Analog input CI | Analog input CI value | 0.01V | | * |
| b-11 | External pulse input | External pulse width input value | 1 Ms | | * |
| b-12 | Inverter rated current | Inverter rated current | 0.1A | | * |
| b-13 | Inverter rated voltage | Inverter rated voltage | 1V | | * |
| b-14 | Without unit display | Without unit display | 1 | | |
| b-15 | Inverter model type | Inverter model type | 1 | | |

3.3 Terminal Monitoring State

Note: Input/output terminal state displayed as follow:



Note: “ / ” Means invalid (LED OFF) “ / ” Means valid (LED ON)

Chapter 4 Serial Port RS485 MODBUS

4.1 Communication protocol specification

The inverter in the RS485 network can be used as the host, can also be used as the machine, used as a host, can control the other inverter, multi-stage tandem, as from a machine, PC or PLC can work as a host control frequency converter Specific communication methods are as follows.

(1) Inverter for from machine, master-slave point-to-point communication host using radio address send command, the machine does not respond.

(2) The inverter used as host, the broadcast address to send the command to from the machine, the machine does not respond.

(3) The user can be set by using a keyboard or a serial communication mode converter of the machine address Baud rate data format.

(4) From the machine to the host in a recent polling reports the current fault information in the response of the frame.

4.2 Communication interface way

Communication for RS485 interface, asynchronous serial port, half-duplex transmission The default way of communication protocol using the ASCII mode.

The default data format for: 1 a start bit, seven bits, two stop bits. The default rate for 9600 BPS, communication parameter Settings see P3.09 ~ P3.12 function code.

4.3 ASCII and RTU MODBUS

Character structure:

Box 10 characters (For ASCII)

(1-7-2 Format, no parity)

| | | | | | | | | | |
|------------|---|---|---|---|---|---|---|-----------|-----------|
| Star t bit | 1 | 2 | 3 | 4 | 5 | 6 | 7 | Sto p bit | Sto p bit |
|------------|---|---|---|---|---|---|---|-----------|-----------|

(1-7-1 Format, odd parity)

| | | | | | | | | | |
|------------|---|---|---|---|---|---|---|------------|-----------|
| Star t bit | 1 | 2 | 3 | 4 | 5 | 6 | 7 | Parity bit | Sto p bit |
|------------|---|---|---|---|---|---|---|------------|-----------|

(1-7-1 Format, even parity check)

| | | | | | | | | | |
|------------|---|---|---|---|---|---|---|------------|-----------|
| Star t bit | 1 | 2 | 3 | 4 | 5 | 6 | 7 | Parity bit | Sto p bit |
|------------|---|---|---|---|---|---|---|------------|-----------|

Box 11 characters (For RTU)

(1-8-2 Format, no parity)

| | | | | | | | | | | |
|------------|---|---|---|---|---|---|---|---|-----------|-----------|
| Star t bit | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | Sto p bit | Sto p bit |
|------------|---|---|---|---|---|---|---|---|-----------|-----------|

(1-8-1 Format, odd parity)

| | | | | | | | | | | |
|------------|---|---|---|---|---|---|---|---|------------|-----------|
| Star t bit | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | Odd parity | Sto p bit |
|------------|---|---|---|---|---|---|---|---|------------|-----------|

(1-8-1 Format, even parity check)

| | | | | | | | | | | |
|------------|---|---|---|---|---|---|---|---|-------------------|-----------|
| Star t bit | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | Even parity check | Sto p bit |
|------------|---|---|---|---|---|---|---|---|-------------------|-----------|

Communication Data Structure:

ASCII Mode

| | |
|--------------|--|
| Pillow | Beginning character = “:” (3AH) |
| Address Hi | Postal address: |
| Address Lo | Eight address by two ASCII combination |
| Function Hi | Function code: |
| Function Lo | Eight address by two ASCII combination |
| DATA (n - 1) | Data content: |
| | N*8 bits of data content by 2*n ASCII combination, high before, and low in the back, n <= 4, the eight largest ASCII |
| DATA 0 | |
| LRC CHK Hi | LRC check code: |
| LRC CHK Lo | Eight check code consists of two ASCII combination |
| END Hi | Termination characters: |
| END Lo | END Hi = CR(0DH), END Lo = CR(0AH) |

RTU Mode:

| | |
|--------------|--|
| START | Keep no input signal is greater than or equal to 10ms |
| Address | Postal address: 8-bit binary address |
| Function | Function Code: 8-bit binary address |
| DATA (n - 1) | Data content: |
| | N*8-bit data, N<=8, Maximum 8 bytes |
| DATA 0 | |
| CRC CHK Low | CRC check code |
| CRC CHK High | 16-bit CRC Check code consists of two 8-bit binary combination |
| END | Keep no input signal is greater than or equal to 10ms |

Postal address:

00H: All inverter radio (broadcast)

01H: To address the inverter communication 01.

0FH: About 15 address inverter communication

10H: About 16 address inverter communication, and so on, Maximum up to 247 (7FH).

Function code (Function) And the material content (DATA):

03H: Read the register contents.

06H: Write money to expect that register.

08H: Loop detection.

10H: Read more register contents.

Function code 03H: Read a register contents:

For example: Read the register address 2104H content (current output):

ASCII Mode:

| Status | Pillow | Address | Function | Content | Check | End | | | | | | | | | | | | |
|-------------|--------|---------|----------|---------|-------|-----|----|----|----|----|----|----|----|----|----|----|----|----|
| Transmit | : | 0 | 1 | 0 | 3 | 2 | 1 | 0 | 4 | 0 | 0 | 0 | 1 | D | 7 | CR | LF | |
| Hexadecimal | | 3A | 30 | 31 | 30 | 33 | 32 | 31 | 30 | 34 | 30 | 30 | 30 | 31 | 44 | 37 | 0D | 0A |
| Response | : | 0 | 1 | 0 | 3 | 0 | 2 | | 0 | 0 | 0 | 0 | D | 7 | CR | LF | | |
| Hexadecimal | | 3A | 30 | 31 | 30 | 33 | 30 | 32 | | 30 | 30 | 30 | 30 | 44 | 37 | 0D | 0A | |

RTU Mode:

| Status | Pillow | Address | Function | Content | Check | End | | | |
|----------------------------|--------|---------|----------|---------|-------|-----|----|----|----|
| Send a hexadecimal | | 01 | 03 | 21 | 04 | 00 | 01 | CF | F7 |
| In response to hexadecimal | | 01 | 03 | 02 | 00 | 00 | B8 | 44 | |

Function code 06H: Write data to the registers.

For example: The inverter address 01H, Write P0.02=50.00HZ function code

ASCII Mode:

| Status | Pillow | Address | Function | Content | Check | End | | | | | | | | | | | | |
|-------------|--------|---------|----------|---------|-------|-----|----|----|----|----|----|----|----|----|----|----|----|----|
| Transmit | : | 0 | 1 | 0 | 6 | 0 | 0 | 0 | 2 | 1 | 3 | 8 | 8 | 5 | C | CR | LF | |
| Hexadecimal | | 3A | 30 | 31 | 30 | 36 | 30 | 30 | 30 | 32 | 31 | 33 | 38 | 38 | 35 | 43 | 0D | 0A |
| Response | : | 0 | 1 | 0 | 6 | 0 | 0 | 0 | 2 | 1 | 3 | 8 | 8 | 5 | C | CR | LF | |
| Hexadecimal | | 3A | 30 | 31 | 30 | 36 | 30 | 30 | 30 | 32 | 31 | 33 | 38 | 38 | 35 | 43 | 0D | 0A |

RTU Mode:

| Status | Pillow | Address | Function | Content | Check | End | | | |
|----------------------------|--------|---------|----------|---------|-------|-----|----|----|----|
| Send a hexadecimal | | 01 | 06 | 00 | 02 | 13 | 88 | 25 | 5C |
| In response to hexadecimal | | 01 | 06 | 00 | 02 | 13 | 88 | 25 | 5C |

Command code: 08H communication circuit test.

This command is used to test whether or not the communication between main control equipment and frequency

converter to normal Inverter will receive information intact to master device.

ASCII Mode:

| Status | Pillow | Address | Function | Content | Check | End | | | | | | | | | | | |
|-------------|--------|---------|----------|---------|-------|-----|----|----|----|----|----|----|----|----|----|----|----|
| Transmit | : | 0 | 1 | 0 | 8 | 0 | 1 | 0 | 2 | 0 | 3 | 0 | 4 | E | D | CR | LF |
| Hexadecimal | 3A | 30 | 31 | 30 | 38 | 30 | 31 | 30 | 32 | 30 | 33 | 30 | 34 | 45 | 44 | 0D | 0A |
| Response | : | 0 | 1 | 0 | 8 | 0 | 1 | 0 | 2 | 0 | 3 | 0 | 4 | E | D | CR | LF |
| Hexadecimal | 3A | 30 | 31 | 30 | 38 | 30 | 31 | 30 | 32 | 30 | 33 | 30 | 34 | 45 | 44 | 0D | 0A |

RTU Mode:

| Status | Pillow | Address | Function | Content | Check | End |
|----------------------------|--------|---------|----------|-------------|-------|-----|
| Send a hexadecimal | | 01 | 08 | 01 02 03 04 | 41 | 04 |
| In response to hexadecimal | | 01 | 08 | 01 02 03 04 | 41 | 04 |

Check code:

ASCII Mode: double byte code ASCII.

Method: the message sender, the calculation method of LRC England is going to send a message from the machine address to run all data not converted to ASCII byte continuous accumulation, discarded carry a result, the bitwise take the 8-bit bytes, and then add 1 (converted to complement), finally converted to ASCII code, in the inspection area, high byte in the former, in the low byte For the receiver of the message, do the same checksum LRC England method receives the message, and the actual received check and compare, and if equal, receives the message correctly If it is not equal to receive error message If the calibration error, the discarded the message frame, does not make any response, continue to receive the next frame data

RTU Mode: Double byte hexadecimal number.

CRC domain is two bytes, containing a 16 bit binary value It is calculated by the sender, after join the message; Add the first low byte, then the high byte, therefore, the high byte of CRC is sending a message of the last byte Receiving device to calculate the CRC messages are received, and compared with receives the CRC in the domain of value, if there are any errors, two different value is receiving messages to discard the message frame, does not make any response, continue to receive the next frame data CRC checking calculation method refer to the MODBUS protocol.

4.4 Communication protocol parameter definition:

| Definition | Parameter address | Function |
|----------------------------------|--|---|
| Internal set parameters | GnH | GG: On behalf of the group of parameters. nn: On behalf of the parameter number |
| For the inverter command (06H) | 2000H | 00B: No function |
| | | 01B: Stop |
| | | 10B: Running |
| | | 11B: Jog |
| | BIT 2~3 | Reserve |
| | BIT 4~5 | 00B: No function |
| | | 01B: Positive direction to run |
| | | 10B: Run the opposite direction |
| | | 11B: Change direction |
| | BIT 6~7 | Reserve |
| 2001H | Serial port command set frequency | |
| 2002H | 00: No function; 01: EF.; 02: Trouble Reset | |
| Monitor the inverter state (03H) | 2100H | Read the inverter fault code |
| | 2101H | Read the inverter state |
| | | BIT0: Running a stop sign;0: Stop;1: Running |
| | | BIT1: Undervoltage logo;1: Undervoltage; 0: Normal |
| | | BIT2: Positive &negative Peugeot;1reversal;0corotation |
| | | BIT3: Inching operation signs;1: Jog; 0: NO jog |
| | | BIT4: Closed loop operation control option;1: Closed loop; 0: not a closed loop |
| | | BIT5: pendulum frequency mod;1: swing frequency; 0: not a swing frequency |
| | | BIT6:PLC running;1: PLC running;0: NO PLC running |
| | | BIT7: Terminal multistage speed operation;1: multistage speed;0: No |
| | | BIT8: Normal operation sign;1: Normal runing;0: No |
| | | BIT9: Main frequency source from the communication interface;1: Yes;0:No |
| | | BIT10: The main frequency source from the analog input;1: Yes;0: No |
| | BIT11: Run command from the communication interface;1: Yes;0: No | |
| | BIT12: Password protection function parameters;1: Yes;0: No | |
| | 2102H | Read inverter set frequency |
| | 2103H | Read the inverter output frequency |
| | 2104H | Read the inverter output current |
| | 2105H | Read the inverter bus voltage |
| | 2106H | Read the inverter output voltage |
| 2107H | Read the motor speed | |
| 2108H | Read the module temperature | |
| 2109H | Read the VI analog input | |
| 210AH | Read the CI analog input | |
| 210BH | Read the inverter software version | |
| Read function code data (03H) | GnH (GG: Function code group no.nn: Function code no.) | Inverter response function code data |
| Write a function | GnH | Write the function of the frequency converter code |

| | | |
|-----------------|--|------|
| code data (06H) | (GG: Function code group no.nn: Function code no.) | data |
|-----------------|--|------|

Error codes defined:

| Error codes | State |
|-------------|--|
| 01H | Function code error frequency converter to ferreting function code: 03H, 06H, 08H. |
| 02H | Data address error data converter can't |
| 03H | Data error information content overrun. |







Chapter 5 Troubleshooting

5.1 Fault Alarm and Troubleshooting

When the inverter is abnormal, protection function acts:LED displays fault code and the content, fault relay acts, the inverter stops output and the motor coasts to stop. VCD2000 series inverters fault contents and troubleshooting is as shown in Table 7-1. After fault alarm occurs, fault phenomenon should be recorded in detail, the fault should be processed according to Table 5-1. When in need of technical assistance, please contact us or your supplier.

Table 5-1 Alarms and troubleshooting

| Fault code | Type of fault | Possible fault reasons | Troubleshooting |
|------------|--|--|---|
| E-01 | Acc over current | Heavy Load. Acc time is too short | Adjust Acc time |
| | | V/F curve setup is not suitable | Adjust V/F curve |
| | | Restart the motor in running | Set start mode as speed tracking restart |
| | | Torque boost setup is too big | Adjust torque boost or set as auto mode |
| E-02 | Dec over current | Inverter capacity is too low | Select inverter with proper capacity |
| | | Dec time is too short | Adjust Dec time |
| E-03 | over current at constant speed running | Potential energy load or load inertia is too big | Add suitable braking device |
| | | Load mutation | Reduce load mutation |
| | | Acc or Dec time is too short | Adjust Acc or Dec time |
| | | Abnormal load | Check load |
| E-04 | Acc ver voltage | Input voltage abnormal | Check input power supply |
| | | Inverter capacity is too low | Select inverter with proper capacity |
| E-05 | Dec over voltage | Input voltage abnormal | Check input power supply |
| | | Acc time is too short | Adjust Acc time |
| E-06 | over voltage at constant speed running | Restart the motor in running | Set start mode as speed tracking restart |
| | | Dec time is too short | Adjust the Dec time |
| E-07 | over voltage of control power supply | Potential energy load or load inertia is too big | Add suitable braking device |
| | | Input voltage abnormal | Check input power supply |
| | | Acc or Dec time is too short | Adjust the Acc or Dec time |
| | | Abnormal change of input voltage | Mount input reactor |
| E-08 | Inverter over heat | Load inertia is too big | Add suitable braking device |
| | | Air duct obstruction | Clean air duct |
| | | Environment temperature is too high | Improve the ventilation or reduce the carrier frequency |
| E-09 | Inverter over load | Fan damaged | Replace a new fan |
| | | Inverter module abnormal | Contact us or supplier |
| | | Acc time is too short | Adjust Acc time |
| | | DC braking value is too high | Reduce DC braking current and add braking time |
| | | V/F curve setup is not suitable | Adjust V/F curve |
| E-10 | Motor over load | Restart the motor in running | Set start mode as speed tracking restart |
| | | Mains voltage is too low | Check mains voltage |
| | | Heavy load | Select inverter with proper capacity |
| | | Common motor runs at low speed with heavy load for long term | Use variable frequency motor |
| E-11 | Under voltage in running | Wrong setting of motor over load protection factor | Set the factor right |
| | | Motor choked or sudden change of load | Check load |
| E-12 | Inverter module protection | Very low mains voltage | Check mains voltage |
| | | V/F curve setup is not suitable | Adjust V/F curve |
| | | Mains voltage is too low | Check mains voltage |
| | | Output 3-phase fault or ground short | Re-wiring |
| | | Air duct obstruction or fan damaged | Clean air duct or replace a new fan |
| | | Environment temperature too high | Reduce environment temperature |
| E-12 | Inverter module protection | Control board connecting wire or plug-in unit loose | Check and re-wiring |
| | | Current waveform abnormal due to output missing phase, etc. | Check wiring |
| | | Auxiliary power damaged, or driving voltage under voltage | Contact us or supplier |


| | | | |
|------|---|--|---|
| | | Control board abnormal | Contact us or supplier |
| E-13 | Peripheral fault | External fault terminal closed | Clear fault |
| E-14 | Current detecting circuit fault | Control board connecting wire or plug-in unit loose | Check and re-wiring |
| | | Auxiliary power source damaged | Contact us or supplier |
| | | Hall component damaged | Contact us or supplier |
| | | Abnormal amplifier circuit | Contact us or supplier |
| E-15 | RS232/485 Communication fault | Wrong baud rate setting | Set baud rate properly |
| | | Serial port communication fault | Press  key to reset or contact us |
| | | Improper fault alarm parameter setting | Revise function code P3.09~P3.12 |
| E-16 | System interference | Upper computer does not work | Check upper computer and connecting cable |
| | | Serious interference | Press  key to reset or install input power source filter |
| E-17 | E ² PROM error | DSP read/write error | Reset or contact us |
| | | Read/write error of control parameter | Press  key to reset, or contact us |
| E-18 | Life timer | Equipment, set the time expires | Please contact the vendors |
| E-21 | Accelerate the instantaneous over-current | In the process of accelerating current moment reached 2.5 times of rated, short circuit protection hardware Output short circuit protection | Because be instantaneous over-current, could be a motor, rapid acceleration and deceleration, or motor phase insulation breakdown, lead to motor and short circuit, short circuit or output circuit, a capacitive load, or output by the contactor, etc, please check Of course not rule out the possibility of the inverter itself current detection device problem. |
| E-22 | Slow instantaneous over-current | In the process of reduction current moment reached 2.5 times of rated, short circuit protection hardware Output short circuit protection | inverter can eliminate this as a replacement if the replaced the inverter or frequently, please be sure to repair or replace the motor, otherwise it is easy to burn the inverter In the motor insulation |
| E-23 | Constant speed instantaneous over-current | In the process of constant speed, or stop instantly at the rated current of 2.5 times, short circuit protection hardware Output short circuit protection | In the motor insulation when please use above 1000 volts shaking table, otherwise, is not allowed for inverter output is high frequency and high voltage square wave, requirements for the insulation of the motor is more than 1200 v So the motor may be under 50 hz380v sine wave voltage mains is normal, using frequency converter will be out of the interphase short circuit |
| E-26 | U phase missing protection | U phase ouput missing fault | Press  key to reset, or check U phase output circuit |
| E-27 | V phase missing protection | V phase ouput missing fault | Press  key to reset, or check V phase output circuit |
| E-28 | W phase missing protection | W phase ouput missing fault | Press  key to reset, or check W phase output circuit |
| E-30 | Module driving protection | Module when they believe there is a short circuit module | Check for short circuit, the output off load to try again, if there is protection module is broken, if not out with a short circuit to screening, can also try other motor, if changed the motor also have the same protection may be adverse to repair module driver |
| E-37 | Self-learning fault | The vector of parameter self-learning pass it | The motor and frequency converter have no good match |

5.2 Fault Record Search

This series inverter record the fault codes occurred in the last 6 times and inverter running parameter when last fault occurred. Please refer to P6 Series.

5.3 Fault Reset

When fault occurred, please select the following methods to recover.

- (1) When fault code is displayed, after ensure safety in reset, press  key to reset.
- (2) Set any one of X1~X8 terminal as external RESET input (function=17),refer to P4 Series.
- (3) Cut off power.



Attention

- (1) Please reset the inverter after clearing the fault throughly, otherwise, the inverter may be damaged.
 - (2) If fault occurs again after reset, please check the cause of fault, continuous reset may damage inverter.
 - (3) Reset the inverter after waiting for 5 minutes when over load or over heat protection occurs.



Prowinch LLC

www.prowinch.com

2545 NW 74th Ave Miami, Florida, 33122

United States

+1 (800) 971-8061

Equipos de Izaje Prowinch Chile Spa

www.prowinch.cl

Parque Riesco 3407, Recoleta,

Región Metropolitana, Chile

+56-2-26218989

Fortis Alloy Mexico S.A. de C.V

www.prowinch.mx

Fortis Alloy Mexico, S.A. de C.V. Vicente Guerrero No. 403

Col. San Miguel, Apodaca, Nuevo Leon,

Mexico C.P. 66649

+52 (81) 8244-1351

Prowinch Colombia SAS

www.prowinch.co

Cl. 163a #20-28, Bogotá, Colombia

+57 1 7034035

Provedora Industrial y Tecnica, S.A. de C.V.

www.prointe.com.sv

Av. Alberto Masferrer Sur, Col. Campestre No. 211

San Salvador, El Salvador

2264-1100

Representaciones Ivankovich RA S.A.

ivankovich.co.cr

100 mt. Este y 300 Mt. Sur de las Oficinas Centrales del

INS, Cartago, Costa Rica

(506) 2553-1415